



# **Prisma II 1310 nm Reverse Transmitter**

## Installation and Operation Guide

# For Your Safety







---

## Explanation of Warning and Caution Icons



**Avoid personal injury and product damage! Do not proceed beyond any symbol until you fully understand the indicated conditions.**

The following warning and caution icons alert you to important information about the safe operation of this product:

-  **You may find this symbol in the document that accompanies this product. This symbol indicates important operating or maintenance instructions.**
-  **You may find this symbol affixed to the product. This symbol indicates a live terminal where a dangerous voltage may be present; the tip of the flash points to the terminal device.**
-  **You may find this symbol affixed to the product. This symbol indicates a protective ground terminal.**
-  **You may find this symbol affixed to the product. This symbol indicates a chassis terminal (normally used for equipotential bonding).**
-  **You may find this symbol affixed to the product. This symbol warns of a potentially hot surface.**
-  **You may find this symbol affixed to the product and in this document. This symbol indicates an infrared laser that transmits intensity-modulated light and emits invisible laser radiation or an LED that transmits intensity-modulated light.**

## Important

Please read this entire guide. If this guide provides installation or operation instructions, give particular attention to all safety statements included in this guide.

# Notices

---

## Trademark Acknowledgments

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at [www.cisco.com/go/trademarks](http://www.cisco.com/go/trademarks).

Third party trademarks mentioned are the property of their respective owners.

The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

## Publication Disclaimer

Cisco Systems, Inc. assumes no responsibility for errors or omissions that may appear in this publication. We reserve the right to change this publication at any time without notice. This document is not to be construed as conferring by implication, estoppel, or otherwise any license or right under any copyright or patent, whether or not the use of any information in this document employs an invention claimed in any existing or later issued patent.

## Copyright

© 2008, 2013 Cisco and/or its affiliates. All rights reserved. Printed in the United States of America.

Information in this publication is subject to change without notice. No part of this publication may be reproduced or transmitted in any form, by photocopy, microfilm, xerography, or any other means, or incorporated into any information retrieval system, electronic or mechanical, for any purpose, without the express permission of Cisco Systems, Inc.

# Contents

---

|   |                                 |
|---|---------------------------------|
| Safety Precautions .....  | v                               |
| Compliance .....  | vii                             |
| Laser Safety .....  | viii                            |
| <br>  |                                 |
| <b>Chapter 1</b>  | <b>Introduction</b>             |
| Overview .....  | 1-1                             |
| Describing the Chassis.....   | 1-2                             |
| The Front Panel.....  | 1-5                             |
| The Back Panel.....   | 1-6                             |
| Configuration Overview .....  | 1-7                             |
| <br>  |                                 |
| <b>Chapter 2</b>  | <b>Installation</b>             |
| Overview .....  | 2-1                             |
| Preparing for Installation .....                                    | 2-2                             |
| Site Requirements.....  | 2-3                             |
| Connecting the RF Cables to the Chassis.....                        | 2-6                             |
| Installing the Module in the Chassis .....                          | 2-7                             |
| Connecting Optical Cables .....                                     | 2-9                             |
| Communications Connections.....                                     | 2-12                            |
| Master/Slave Connections.....                                       | 2-14                            |
| <br>  |                                 |
| <b>Chapter 3</b>  | <b>Operation Using the ICIM</b> |
| Overview .....  | 3-1                             |
| ICIM Introduction .....   | 3-2                             |
| The ICIM Front Panel .....  | 3-3                             |
| The ICIM Password.....  | 3-6                             |
| Operating the ICIM .....  | 3-11                            |
| Monitoring Operating Status Using the ICIM.....                     | 3-14                            |
| Configuring the 1310 nm Reverse Transmitter Using the ICIM.....     | 3-17                            |
| Checking the 1310 nm Reverse Transmitter Alarms Using the ICIM..... | 3-20                            |
| Checking Manufacturing Data Using the ICIM.....                     | 3-24                            |
| Using the ICIM to Save the Configuration .....                      | 3-27                            |

## Contents, Continued

---


|                       |  |                    |
|-----------------------|--|--------------------|
| <b>Chapter 4</b>      | <b>Operation Using LCI</b>                               |                    |
|                       | LCI Introduction .....                                   | 4-3                |
|                       | System Requirements.....                                 | 4-4                |
|                       | Installing LCI.....                                      | 4-5                |
|                       | Connecting Your Laptop Computer to the Chassis.....      | 4-9                |
|                       | Installing LCI.....                                      | 4-10               |
|                       | LCI Module Tree Overview .....                           | 4-11               |
|                       | Accessing the Module Details Window .....                | 4-13               |
|                       | Checking the Operating Status.....                       | 4-20               |
|                       | Configuring the 1310 nm Reverse Transmitter .....        | 4-22               |
|                       | Checking 1310 nm Reverse Transmitter Alarms.....         | 4-25               |
|                       | Modifying 1310 nm Reverse Transmitter Alarm Limits ..... | 4-27               |
|                       | Checking Manufacturing Data .....                        | 4-29               |
| <br>                  |  |                    |
| <b>Chapter 5</b>      | <b>Maintenance and Troubleshooting</b>                   |                    |
|                       | Overview .....   | 5-1                |
|                       | Prisma II Module Maintenance .....                       | 5-2                |
|                       | General Troubleshooting Information .....                | 5-3                |
|                       | Troubleshooting Alarm Conditions.....                    | 5-4                |
| <br>                  |  |                    |
| <b>Chapter 6</b>      | <b>Customer Information.....</b>                         | <b>6-1</b>         |
| <br>                  |  |                    |
| <b>Glossary</b> ..... |  | <b>Glossary -1</b> |

# Safety Precautions

---

## Protect Yourself From Electric Shock and Your System From Damage!

- This product complies with international safety and design standards. Observe all safety procedures that appear throughout this guide, and the safety symbols that are affixed to this product.
- If circumstances impair the safe operation of this product, stop operation and secure this product against further operation.



**Avoid personal injury and product damage! Do not proceed beyond any symbol until you fully understand the indicated conditions!**



You will find this symbol in the literature that accompanies this product. This symbol indicates important operating or maintenance instructions.



You may find this symbol affixed to this product. This symbol indicates a live terminal; the flash points to the terminal device.



You may find this symbol affixed to this product. This symbol indicates a protective earth terminal.



You may find this symbol affixed to this product. This symbol indicates excessive or dangerous heat.

---

*Continued on next page*

## Safety Precautions, Continued

---

### Factory Service

Refer service only to service personnel who are authorized by the factory.

### Enclosure

- Do not allow moisture to enter this product.
- Do not open the enclosure of this product unless otherwise specified.
- Do not push objects through openings in the enclosure of this product.

### Cables

- Always pull on the plug or the connector to disconnect a cable. Never pull on the cable itself.
  - Do not walk on or place stress on cables or plugs.
-

# Compliance

---

## Laser and Electrical Safety

**UL 1419:1997:** A sample of this equipment has been tested and found to meet the requirements of UL 1419:1997.

**CSA C22.2 No. 1:1994:** A sample of this equipment has been tested and found to meet the requirements of CSA C22.2 No. 1:1994.

**21 CFR:** A sample of this equipment has been tested and found to meet the requirements of 21 CFR chapter 1, subchapter J.

## Electromagnetic Compatibility

**FCC Part 15 Subpart B:** This equipment has been tested and found to comply with the limits for a Class A digital device according to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

**Industry Canada ICES-003:** This Class A digital apparatus meets all the requirements of the Canadian Interference-Causing Equipment Regulations.

**Industrie Canadienne ICES-003:** Cet appareil numérique de la class A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

---



# Laser Safety

---

## Introduction

This product contains an infrared laser that transmits intensity-modulated light and emits invisible radiation.

## Warning: Radiation

 **WARNING:**

- **Avoid personal injury! Use of controls, adjustments, or procedures other than those specified herein may result in hazardous radiation exposure.**
- **Avoid personal injury! The laser light source on this product emits invisible laser radiation. Avoid direct exposure to the laser light source.**

- Do not apply power to this product if the fiber is unmated or unterminated.
- Do not stare into an unmated fiber or at any mirror-like surface that could reflect light that is emitted from an unterminated fiber.
- Do not view an activated fiber with optical instruments.

## Warning: Fiber Chips

 **WARNING:**

**Avoid personal injury! Wear safety glasses and use extreme caution when you handle the glass chips that are inside the cladding of the optical fiber. X-ray cannot detect these glass chips if they become embedded in the skin. Place the chips immediately in a small waste container and discard.**

## Modifications

Do not make modifications to this product without the approval of Cisco Systems, Inc.

Whenever modifications that may affect hazard levels are made to the optical fiber communication system, the person or organization that performs such modification must reassess hazard levels. They must do this by conducting tests and measurements wherever appropriate for the ensurance of compliance. If there is a change in the hazard level, they must re-label this product.

## Laser Safety, Continued

---

### Maximum Laser Power

The maximum laser power that can be passed through this product, due to misadjustment or component failure, is 30 mW.

### Laser Warning Labels

The Prisma II 1310 nm Reverse Transmitter bears the following labels.



# Chapter 1

## Introduction

### Overview

---

#### Introduction

This chapter describes the front and back panels, and gives configuration overview for the Prisma™ II 1310 nm Reverse Transmitter.

#### Qualified Personnel

Only appropriately qualified and trained personnel should attempt to install this product.



**WARNING:**

**Allow only qualified personnel to install, operate, maintain, and service this product. Otherwise, personal injury or equipment damage may occur.**

#### In This Chapter

This chapter contains the following topics.

| Topic                              | See Page |
|------------------------------------|----------|
| Describing the Reverse Transmitter | 1-2      |
| The Front Panel                    | 1-5      |
| The Back Panel                     | 1-6      |
| Configuration Overview             | 1-7      |

# Describing the Reverse Transmitter

---

## Overview

The Prisma II 1310 nm Reverse Transmitter is part of a family of products in the Prisma II product line. These modules are plug-in modules for the Prisma II platform.

This product is intended for reverse transmission of signals over a fiber optic link from hub to headend. The Prisma II Reverse Transmitter is to be used in conjunction with the Prisma II Dual Reverse Receivers and together they comprise the reverse path section of the system.

## Features

The Prisma II Reverse Transmitter has the following features:

- Front panel green LED to indicate operating status
- Front panel red LED to indicate alarm status
- -20 dB test point
- Optical output connectors
- Plug-and-play capability
- Compatible with Cisco LCI and TNCS Software
- Blind mate RF connections

## Describing the Reverse Transmitter, Continued

---

### Reverse Transmitter Operation

The Prisma II 1310 nm Reverse Transmitter receives an RF signal through a connector on the rear of the module. That RF signal is amplified, then converted to an optical signal. This module employs a high performance uncooled, doubly isolated DFB laser to generate the optical signal.

First, the incoming RF signal is amplified. The signal is routed through a coupler and is sent to an RF detector circuit. The detector circuit produces a DC voltage that is proportional to the incident RF power. This voltage level is used to monitor the input power level. The transmitter will generate an alarm condition if the input power is over or under a specified level.

If necessary, an attenuator is used to reduce RF power in an overdrive condition, or to compensate for gain variations of the transmitter. The signal is equalized, then impedance-matched, then sent to the laser. The optical output connector is located on the front panel of the module.

The user can turn the laser on or off, adjust the drive level to the laser, and set alarm levels. The module is controlled by an ICIM, the LCI software, or the TNCS software.

### Optical Output

Depending on how you ordered your system, the optical output connectors may either be an SC/APC, SC/UPC, FC/UPC, or E2000/APC.




#### **WARNING:**

**Avoid damage to your eyes! Do not look into any optical connector while the system is active. Even if the unit is off, there may still be hazardous optical levels present.**

# Describing the Reverse Transmitter, Continued

## Block Diagram

A block diagram of the Prisma II 1310 nm Reverse Transmitter is shown below.



# The Front Panel

---


## Overview

The features of the front panel of the Prisma II 1310 nm Reverse Transmitter are shown below.

| Part              | Function  |
|-------------------|---|
| Alarm Indicator   | Illuminates or blinks when an alarm condition occurs. |
| Power Indicator   | Illuminates when the laser is active.                 |
| Optical Output    | Connects the output signal to the optical cable.      |
| -20 dB Test Point | Provides a -20 dB sample of the RF input signal.      |

## Illustration

The front panel of the Prisma II 1310 nm Reverse Transmitter is shown below.




# The Back Panel

---

## Back Panel Connectors

Blind-mate connectors make it easy to install this module. The connector on the back of the module mates with a connector on the inside of the chassis. The 110-pin connector provides the following:

- RF signal input connection
- Electrical power input connection
- Alarm communications
- Status-monitoring communications
- Communications and control connections



## Power and Communications Connector

The power and communications connector on the back of the module mates with a connector inside of the chassis, and supplies power from the chassis to the transmitter. The 110-pin connector also routes alarm and status-monitoring information from the transmitter to the Prisma II Chassis.



# Configuration Overview

---

## Overview

The Prisma II Reverse Transmitter is shipped from the factory with operational parameters set to factory defaults. However, you may choose to configure the operating parameters so that they are best suited for your application.

## Configuration and Monitoring Methods

The Prisma II 1310 nm Reverse Transmitter may be controlled using one of three different methods.

- The Prisma II Intelligent Communications Interface Module (ICIM)

If an ICIM is installed in the Prisma II Chassis, it may be used to configure and monitor Prisma II application modules within its domain. For instructions on operating this module using the ICIM, refer to Chapter 3, **Operation Using the ICIM**.

- The Local Craft Interface (LCI) software

The Local Craft Interface (LCI) software running on a locally connected PC may be used to configure operating parameters of Prisma II modules. For instructions on operating this module using the LCI software, refer to Chapter 4, **Operation Using LCI**.

- Cisco's Transmission Network Control System (TNCS) software.

If the ICIM is installed, TNCS software may be used to configure and monitor all functions of the Prisma II modules. For instructions on operating this module using TNCS, see the manual that was shipped with the TNCS software, *TNCS Administrator Software User's Guide*, part number 730201.

## Configuration Summary

Using any of the above methods, you can configure the following parameters.

- Enable or disable transmitter operation
- Normal or CwMode
- Enable or disable the "RF input low" alarm
- Configure the module as master or slave
- Set the relative RF drive level into the transmitter
- Return to the factory default settings

For detailed information on configuring this module, see Chapter 3, **Operation Using the ICIM** or Chapter 4, **Operation Using LCI**.

# Chapter 2 Installation

## Overview

---

### Introduction

This chapter contains instructions, site requirements, equipment, and tools needed to install the Prisma II 1310 nm Reverse Transmitter.

### Qualified Personnel



**WARNING:**

**Allow only qualified personnel to install, operate, maintain, or service this product. Otherwise, personal injury or equipment damage may occur.**

### In This Chapter

This chapter gives step-by-step instructions on installing the Prisma II Transmitter.

| Topic                                   | See Page |
|---|----------|
| Preparing for Installation              | 2-2      |
| Site Requirements                       | 2-3      |
| Connecting the RF Cables to the Chassis | 2-6      |
| Installing the Module in the Chassis    | 2-7      |
| Connecting Optical Cables               | 2-9      |
| Communications Connections              | 2-12     |
| Master/Slave Connections                | 2-14     |

# Preparing for Installation

---

## Overview

Before you begin, make that you have the tools and equipment listed here.

## Unpacking and Inspecting the Module

As you unpack the module, inspect it for shipping damage. If you find any damage, contact Cisco. Refer to Chapter 6 for information on contacting Cisco's Technical Assistance Center.

## Equipment and Tools Needed

Before you begin, make sure that the module is in good condition. You need the following equipment and tools to install these modules.

| <b>You need . . .</b>                 | <b>To . . .</b>  |
|---------------------------------------|--|
| a Prisma II Chassis with power supply | provide housing, power and input/output connections to the module. |
| 3/8-in. flat-blade screwdriver        | secure the module in the chassis.                                  |
| one RF cable with connectors          | carry RF input signals.  |

# Site Requirements

---

## Overview

Before you begin, make certain that your installation site meets the requirements discussed in this section.

## Access Requirements

Ensure that only authorized personnel have access to this equipment. Otherwise, personal injury or equipment damage may occur.



**WARNING:**

**Use this product in locations that restrict access to all persons who are not authorized. Otherwise, personal injury or equipment damage may occur.**

## Equipment Rack

To install the modules, your site should be equipped with an Electronics Industry Association (EIA) equipment rack that properly houses the Prisma II Chassis with proper spacing for air circulation. For instructions on installing the chassis in the rack, refer to the guide that was shipped with the chassis.

## Operating Environment



**CAUTION:**

**Avoid damage to this product! Operating this product above the maximum operating temperature specified voids the warranty.**

Follow these recommendations to maintain an acceptable operating temperature.

- Temperature inside the rack must be between -40°C and 65°C (-40°F and 149°F)
- Keep cooling vents clear and free of obstructions.
- Provide ventilation, as needed, using one or more of the following methods.
  - air-deflecting baffles
  - forced-air ventilation
  - air outlets above enclosures

## Site Requirements, Continued

---

### Power Requirements

Prisma II modules receive their electrical power from the Prisma II Chassis. The module may be installed with the chassis powered-up.

### Space Requirements

This module is a single-width module. It is usually installed in slots 5 through 16. Slots 1 through 4 are usually reserved for the power supplies. Slots 15 and 16 are reserved for the Intelligent Communications Interface Module (ICIM), if installed. If an ICIM is not installed, any other module could be installed in these slots. Slot 2 and slot 4 are reserved for an internal power supply if installed. If an internal power supply is not installed here, any other module could be installed in these slots.


### Chassis Style

The Prisma II Chassis may be configured with front or rear connectors depending on the system you have purchased. Power, RF input/output, and other connectors may be located on either the front or rear of the Prisma II Chassis. Connections to the chassis serve the same function and are made in the same manner regardless of the location of the connectors or chassis configuration.

# Site Requirements, Continued

## Rear Access Chassis Illustration


The Prisma II Chassis may be configured with front or rear connectors depending on the system you have purchased. The rear access chassis is shown here.



Ta036

## Front Access Chassis Illustration

The front access chassis is shown here.



Ta035


# Connecting the RF Cables to the Chassis

## RF Cable Connection Procedure


**Important:** This procedure assumes the Prisma II Chassis is mounted in a rack.

Follow this procedure to make the RF cable connections for each transmitter to be installed.

1. Attach a 75-ohm RF cable to the appropriate RF source.
2. At the front/rear of the Prisma II Chassis, locate the RF ports.



3. Attach the other end of the RF cable to Port A connector (RF IN) of the corresponding slot where the module is to be installed. This is the RF input connection.



4. If F-connectors are installed, use a 7/16-in. open-end wrench, secure both cables to the connectors at the chassis.
5. Proceed to the next section, **Installing the Module in the Chassis**.


# Installing the Module in the Chassis

## Installing the Module

**Important:** The following procedure assumes the Prisma II Chassis is mounted in a rack. This procedure applies to both chassis styles.

This module is usually installed in slots five through sixteen. To install the module in the chassis, follow these steps.

1. Locate the fiber guides at the bottom of the chassis and the module guide slots inside the chassis as shown in the following illustration.



2. Align the ridges on the top and bottom of the module with the module guide slots located on the chassis. Module ejectors must be fully extended when inserting the module.




## Installing the Module in the Chassis, Continued

---

3. Gently slide the module into the chassis until you feel the power and communications connections on the back of the module join connectors on the backplane. Use the module ejectors on the left side of the module to lock the module in place.

**Note:** Do not force or bang the module into the chassis. If properly aligned, it should slide in with minimal force.




4. Hand-tighten the screw at the top of the module, to secure it in the chassis. Use a  $\frac{3}{8}$ -in. flat-blade screwdriver to secure. **Do not over tighten.**

# Connecting Optical Cables

---


## The Fiber Fish Tool

The Fiber Fish tool that was shipped along with the Prisma II Chassis is used to pull an optical cable from the rear of the chassis to the front of the chassis so the optical cables can be connected to optical connectors on the front panel of Prisma II modules.



## The Fiber Fish Tool Hook

At the end of the Fiber Fish tool is a small hook that allows you to hold an optical cable so that you can pull it through to the front panel of Prisma II Chassis.




## Connecting Optical Cables, Continued

---

### Using the Fiber Fish to Pull the Optical Cable to the Prisma II Module

To pull the an optical cable to the Prisma II module, follow these procedures.

1. Insert the Fiber Fish tool through the slot located just above the bottom of the chassis.
2. At the rear of the chassis, locate the appropriate optical cable.
3. Insert the optical cable into notched area of the Fiber Fish tool as shown.



4. At the front of the chassis, pull the Fiber Fish tool (with cable attached) to the front of the chassis.
5. Disengage the optical cable from the Fiber Fish tool and attach to the appropriate connector on desired module. See **Cable Connection Procedure**.

## Connecting Optical Cables, Continued


---

### Cable Connection Procedure

**Important:** This procedure assumes the Prisma II Chassis is mounted in a rack.

Follow this procedure to make the optical cable connections for each module to be installed.

1. Attach one end of the optical cable to the optical output connector (connector 1), located on the front of the module.



2. Route the other end of the optical cable to the appropriate destination.

# Communications Connections

---

## ICIM IN/ICIM OUT and EM IN/EM OUT Cables

The Prisma II platform allows several chassis to be interconnected. These connections allow the modules to communicate with the ICIM and also allow ICIM to communicate with TNCS.

The cable required for the ICIM IN/ICIM OUT chassis connection is identical to the EM IN/EM OUT cable. This cable is a standard “off the shelf” serial extension cable, DB9 Female to DB9 Male. This cable can be purchased at your local computer store.

The Cisco part number for a 6-foot DB9 Female to DB9 Male extension cable is 180143.

The connectors are a Serial - 9 pin D-shell (EIA 574/232).

## EM IN/EM OUT to TNCS Cable

The connection from the Prisma II Chassis to the TNCS connection requires a special cable kit available from Cisco. Prisma II Cable Kit, part number 738686, includes the following cables:

- 1ea Prisma II Cable Assembly
- 1ea DB9 to DB9 Cable Assembly, 10 foot
- 4ea DB9 to DB9 Cable Assembly, 3 ½ foot

## ICIM IN/ICIM OUT Connections

The Prisma II platform allows multiple chassis to be connected for module to ICIM communications. This connection is required for all chassis intended to be controlled by an ICIM.

**Note: An ICIM can control a maximum of 82 modules. Depending on your application this is typically 6 to 7 chassis. Do not exceed these limits.**

The chassis has two DB9 connectors for the ICIM to module connections. ICIM OUT is a male connector and ICIM IN is a female connector.



## Communications Connections, Continued

---

### ICIM IN/ICIM OUT Connection Procedure

To make ICIM IN/ICIM OUT connections, follow these steps.

1. Connect the DB9 to DB9 cable, part number 180143 or equivalent, from the ICIM OUT of the chassis containing the ICIM to the ICIM IN connector of the second chassis.
2. Connect a DB9 to DB9 cable from the ICIM OUT of the second chassis to the ICIM IN of the third chassis.
3. Continue this “daisy-chain” connection until all desired chassis are connected.

#### Notes:

- All chassis connected in this “daisy-chain” must be powered and have a fan tray installed. A chassis that is connected but is either not powered, or does not have a fan tray installed will cause faulty operation of the ICIM.
- All chassis connected in this “daisy-chain” must have a unique chassis I.D. number.

### EM OUT / IN Connections

The Prisma II platform allows the interconnection of multiple ICIMs located in separate chassis. This connection is required for all ICIMs that you intend to monitor using TNCS and must be completed between each chassis containing an ICIM.

The back panel of the chassis has two DB9 connectors for the TNCS to ICIM connection. The EM OUT is a male connector and the EM IN is a female connector.



### EM OUT / EM IN Connection Procedure


To make EM IN/EM OUT connections, follow these steps.

1. A connection is required from the first chassis containing an ICIM to the TNCS system. The Prisma II Cable Kit (738686) is required for this connection. Connect this cable to the EM IN of the first chassis containing an ICIM.
2. Utilizing a DB9 to DB9 cable (180143 or equivalent), connect the EM OUT of the first chassis to the EM IN of a second chassis containing an ICIM.
3. Continue this “daisy-chain” connection until all chassis containing an ICIM are connected.

# Master/Slave Connections

## Master/Slave Operation

The Prisma II 1310 nm Reverse Transmitter ships from the factory configured as a "Master". LCI, TNCS, or the ICIM can be used to reconfigure the module as a "Slave." The Prisma II Chassis allows for local hard-wired redundancy by using the ALARM IN and ALARM OUT connectors located on the chassis. You can configure a pair of modules so that if the master fails, the slave will take over.



### Notes:

- The ALARM RELAYS are shown in their NORMAL (non-alarmed) state. When a CRITICAL FAULT occurs, the relay changes to the open state.
- Then ENABLE CONTROL is shown in its OFF position. LCI, TNCS, or the ICIM can be used to change its position.

## Master/Slave Connections, Continued

---

### Alarm In/Out Connector Reference

For ALARMS IN/OUT pin connector reference, see **Alarm I/O and Master/Slave Chassis Connections** in Chapter 2 of *Prisma II Chassis Installation and Operation Guide*, part number 713375.

A module configured as a slave normally has its output turned off or disabled. When a critical alarm occurs in the master module, the master turns off and the slave module turns on. To make that happen, the ALARM OUT contacts from the master's slot must be wired to the ALARM IN contacts on the slave 's slot. Once those contacts are wired, care must be taken to ensure that the master and slave modules don't change slots (otherwise the ALARM IN and ALARM OUT connectors will need to be rewired).

Note that any device configured as a master ignores its ALARM IN contacts.

One way to verify proper wiring and configuration is to simply unplug the master device and observe that the slave device turns on.



# Chapter 3

## Operation Using the ICIM

### Overview

---

#### Introduction

The procedures in this chapter apply if you are using the Prisma II Intelligent Communications Interface Module (ICIM) to configure and operate the Prisma II 1310 nm Reverse Transmitter.

#### Scope of This Chapter

Included in this chapter are descriptions of the ICIM front panel and the ICIM LCD, and detailed procedures on how to use the software menus to configure the transmitter.

#### In This Chapter

This chapter contains the following topics.

| Topic  | See Page |
|--|----------|
| ICIM Introduction  | 3-2      |
| The ICIM Front Panel                                       | 3-2      |
| The ICIM Password  | 3-6      |
| Operating the ICIM   | 3-11     |
| Monitoring Operating Status Using the ICIM                 | 3-14     |
| Configuring the 1310 nm Reverse Transmitter Using the ICIM | 3-17     |
| Checking 1310 nm Reverse Transmitter Alarms Using the ICIM | 3-20     |
| Checking Manufacturing Data Using the ICIM                 | 3-24     |
| Using the ICIM to Save the Configuration                   | 3-27     |



#### **WARNING:**

**Avoid damage to your eyes! Do not look into any optical connector while the system is active. Even if the unit is off, there may still be hazardous optical levels present.**

# ICIM Introduction

## ICIM Function

The ICIM functions as the module-user interface as well as the interface between the Prisma II modules and the Transmission Networks Control Systems (TNCS). The ICIM allows local module configuration and status monitoring for up to 82 modules located in multiple chassis. The ICIM features easy-to-use software that is navigated using the numeric keypad and the LCD display.


**Important:** Do not operate any Prisma II Chassis without a fan tray installed properly. If a fan tray is not installed in the Prisma II Chassis, the ICIM will not communicate with any of the modules in that chassis.

**Important:** All chassis connected in a “daisy-chain” must be powered and have a fan tray installed. A chassis that is connected but is either not powered, or does not have a fan tray installed will cause faulty operation of the ICIM.

**Important:** All chassis connected in this “daisy-chain” must have a unique chassis I.D. number.

## ICIM Block Diagram

The ICIM is illustrated in the block diagram below.




# The ICIM Front Panel

---

## ICIM Front Panel Illustration

The following illustration shows the front panel of the ICIM.



## The ICIM Front Panel, Continued

---

### ICIM Front Panel Features

| Part                  | Function   |
|-----------------------|--|
| LCD screen            | Displays the ICIM menus, alarms, and status information.                 |
| 12-key numeric keypad | Used to navigate the ICIM's menus and configure the application modules. |
| Ethernet Connector    | Directly connects the ICIM to a network (future release).                |

### The ICIM LCD

The ICIM LCD is the operator's visual link to the ICIM software. When the ICIM is installed and powered up, the **MAIN** menu is displayed on the LCD. The following illustration shows the ICIM's **MAIN** menu.













|                |
|----------------|
| <b>MAIN</b>    |
| -----          |
| <b>Offline</b> |
| -----          |
| <b>Modules</b> |
| <b>15</b>      |
| -----          |
| <b>Alarms</b>  |
| <b>0</b>       |
| -----          |
| <b>Scroll</b>  |
| -----          |
| <b>Module</b>  |
| <b>Shelf</b>   |
| <b>Slot</b>    |

## The ICIM Front Panel, Continued

---

### The ICIM Key Pad

The ICIM keypad has twelve keys that allow you to input and monitor operational parameters. The table below lists each key and a brief description of its function.

| Button  | Function   |
|---|--|
|    | Displays status information for the selected module  |
|    | Displays configuration information for the selected module   |
|    | Displays all of the parameters in alarm for a selected module  |
|    | Moves the menu selection area up. Also increases numerical readings of selected configuration parameters   |
|    | Moves the menu selection area down. Also decreases numerical readings of selected configuration parameters |
|    | Selects the highlighted parameter  |
|    | Displays ICIM module information such as firmware version, serial number, and baud rate                    |
|  | Shifts function of a keypad button to the function or number label just above that button.                 |
|  | Decreases numerical readings of selected configuration parameters  |
|  | Increases numerical readings of selected configuration parameters  |
|  | Enters input data (if valid)   |
|  | Exits the current menu and displays the MAIN ICIM menu   |

# The ICIM Password

---

## Using the ICIM Password

The ICIM allows you to send configuration commands, to change alarm thresholds, and restore factory default settings in Prisma II modules. In order to ensure that no unauthorized changing of these parameters occurs, you have the option of using a password protection system. Password authorization only applies to the configurable parameters. Status and alarm information is always available on the ICIM regardless of password implementation.

The password system consists of:

- A user-settable password - **User Psw**. The user password is created, entered, and changed through the ICIM keypad and displayed on the ICIM LCD. The password must be exactly eight digits using only the 0-9 number keys.
- A service password - **SA Psw**. Used only by Scientific-Atlanta personnel.
- The ability to change an existing user password - **Change Psw**.
- The ability to disable the user password function - **Disable Psw**.

**Important:** If you only want to monitor status and alarm data, simply skip the password function when it appears on the ICIM menu. You can access all module status and alarm information without a password. However, once a user password is entered, you are required to enter it every time you want to set configurable parameters to any module controlled by that ICIM. See **Expired Password or Inactive Password Messages** and **Entering the User Password** that follow.



## The ICIM Password, Continued

### Entering the User Password

If you wish to use the user password feature, you must create and enter a password of exactly eight digits using only the 0-9 number keys. The password remains active for 10 minutes after your last keystroke. If you want to change configuration parameters after more than 10 minutes, you are required to re-enter your password. To enter a user password, follow the steps below.

1. Access the Password menu as shown earlier in **Accessing the Password Menu**.
2. Press the **SEL** key. The user password menu is displayed.
3. When **User Psw/Shift Off** is displayed, press the **SHIFT** key to display **Shift On** - then enter the eight digits of your password, using the 0-9 number keys. If at any time you input a digit that is incorrect or you wish to change a digit, use the **CAN** (Cancel) function by pressing the **ALRM** key to delete that digit.
4. Press the **ENTER** key to enter the password. The ICIM updates the display to show if your password entry was accepted or rejected. If the entry was accepted you are able to return to the MAIN menu.
5. If the password you entered is rejected, press the **SHIFT** key to return to the password menu, then re-enter an 8-digit password using only the 0-9 number keys. Press the **ENTER** key to input the password.

Reasons for a password to be rejected include:

- Entering more than eight digits for the password
- Pressing keys other than the 0-9 number keys
- Entering an incorrect password if a valid password has been entered








| ICIM               | ICIM               | ICIM                  | ICIM                  |
|--------------------|--------------------|-----------------------|-----------------------|
| Shelf 0<br>Slot 15 | Shelf 0<br>Slot 15 | Shelf 0<br>Slot 15    | Shelf 0<br>Slot 15    |
| User Psw           | User Psw<br>.....  | User Psw<br>1234***** | User Psw<br>12345678  |
| Shift Off          | Shift On           | Rejected<br>Shift Off | Accepted<br>Shift Off |




# The ICIM Password, Continued

## Changing the User Password

If a user password has been entered, it may be changed. However, the current password must be active prior to changing it. If the current password has expired (more than 10 minutes have passed since your last keystroke), you must re-enter the current password before changing to a new one.

1. Access the Password menu as shown in the procedure **Accessing the Password Menu**.
2. Use the  key to scroll down until **Change Psw** is highlighted.
3. Press the  key to select **Change Psw**.
4. When **Change Psw /Shift Off** is displayed, press the  key to display **Shift On** - then enter the eight digits of your new password, using the 0-9 number keys. If at any time you input a digit that is incorrect or wish to change a digit, use the **CAN** (Cancel) function by pressing the  key to delete that digit.
5. Press the  key to input the new password. The ICIM updates the display to show if your password entry was accepted or rejected. If the entry was accepted you are able to return to the MAIN menu.
6. If the new password you entered is rejected, press the  key to return to the password entry menu. Clear all digits using the **CAN** (Cancel) function, then re-enter an 8-digit password using only the 0-9 number keys. Press the  key to input the password.




## The ICIM Password, Continued

---

### Disabling the User Password

If a user password has been entered, you may disable it at any time. However, the current password must be active prior to disabling it. If the current password has expired (more than 10 minutes have passed since your last keystroke), you must re-enter the current password before disabling it.

1. Press the **ICIM** key.
2. Use the **▼** key to scroll down until **Password** is highlighted.
3. Press the **SEL** key.
4. Use the **▼** key to scroll down until **Disable Psw** is highlighted.
5. Press the **SEL** key to select **Disable Psw**.
6. If the current password is active, the menu displays **Password Is Now Disabled**. You can now make changes to parameters without any password.
7. If the current password has expired (more than 10 minutes have passed since your last keystroke), the menu will display **Failed, Password Not Active**. You must re-enter the current password and then repeat this procedure.



# Operating the ICIM

---

## Using the ICIM

Once the module is installed as described in Chapter 2, it runs without the aid of an operator. Unless alarms are generated or your system configuration changes, you should not need to make any adjustments to the module beyond the initial setup.

## Accessing the ICIM LCD Contrast

To access the ICIM LCD contrast control from the MAIN menu, press the **ICIM** key. Use the **+** key to increase or the **-** key to decrease ICIM display contrast.

## The MAIN Menu

A few seconds after power-up, the MAIN menu (shown below) is displayed. Press the **SEL** key to select the specific option.

| Display           | Description  |
|-------------------|--|
| Offline           | Indicates TNCS communication status with the ICIM.   |
| Modules           | Indicates the number of modules in the ICIM domain.  |
| Alarms            | Displays the number of modules that are in alarm. Selecting this option allows scrolling through all modules in alarm condition. |
| Scroll            | Allows scrolling through all modules in the ICIM domain.   |
| Module Shelf Slot | Allows selection of any specific module in the ICIM domain.  |

|             |
|-------------|
| <b>MAIN</b> |
| -----       |
| Offline     |
| -----       |
| Modules     |
| 15          |
| -----       |
| Alarms      |
| 0           |
| -----       |
| Scroll      |
| -----       |
| Module      |
| Shelf       |
| Slot        |

## Operating the ICIM, Continued

### Prisma II ICIM Menu

To display the ICIM menu, press the **ICIM** key. The ICIM menu (shown below) is displayed. Press the **SEL** key to select the specific option.

| Display           | Description  |
|-------------------|--|
| <b>Shelf Slot</b> | Displays the location of the ICIM module.  |
| <b>Mfg Data</b>   | Displays manufacturing data about the ICIM.  |
| <b>Password</b>   | Allows you to enter, change, or disable a system password. See <b>Using the ICIM Password</b> earlier in this chapter.   |
| <b>Update Adr</b> | If the Chassis ID number switch has been changed, you must highlight the <b>Update Adr</b> menu and press the <b>SEL</b> key for the ICIM to recognize the change. |

| ICIM            |    |
|-----------------|----|
| Shelf           | 0  |
| Slot            | 15 |
| -----           |    |
| <b>Mfg Data</b> |    |
| -----           |    |
| Password        |    |
| -----           |    |
| Update Adr      |    |


| ICIM            |    |
|-----------------|----|
| Shelf           | 0  |
| Slot            | 15 |
| -----           |    |
| Mfg Data        |    |
| -----           |    |
| <b>Password</b> |    |
| -----           |    |
| Update Adr      |    |

| ICIM              |    |
|-------------------|----|
| Shelf             | 0  |
| Slot              | 15 |
| -----             |    |
| Mfg Data          |    |
| -----             |    |
| Password          |    |
| -----             |    |
| <b>Update Adr</b> |    |

# Operating the ICIM, Continued


## Prisma II MAIN Menu and ICIM Menu Structure

Pressing the **MAIN** key or the **ICIM** key initiates the MAIN or ICIM software menus. The MAIN and ICIM software structures are shown below.



## Prisma II 1310 nm Reverse Transmitter Software Menu Structure

From the MAIN or SCROLL menus, you can navigate to the Prisma II 1310 nm Reverse Transmitter MODULE menu. From the MODULE menu, press the **STAT**, **CFG**, or **ALRM** key to display the desired parameter menu.



## Monitoring Operating Status Using the ICIM

---

### Monitored Parameters













You can monitor the status of operating parameters. The table below describes the monitored parameters for this module.

| <b>Parameter</b> | <b>Units</b> | <b>Function</b>                              |
|------------------|--------------|--|
| OutPwr           | dBm          | Displays optical output power                |
| LasBias          | mA           | Displays laser bias current                  |
| InRF             | dB           | Displays RF input level                      |
| ModTemp          | °C           | Displays module temperature                  |
| TecCur           | mA           | Displays laser thermoelectric cooler current |
| LasTemp          | °C           | Displays laser temperature                   |
| Enable           | N/A          | Laser on/off                                 |
| CwMode           | N/A          | Continuous wave mode operation               |
| LoRFInh          | N/A          | Low RF alarm enabled/disabled                |
| Master           | N/A          | Master or Slave operation                    |
| RFDrive          | N/A          | RF drive level                               |

# Monitoring Operating Status Using the ICIM, Continued

## Checking Operating Status

Using the ICIM LCD you can check the status of all operating parameters of this module. To monitor the module operating parameters, follow these steps.

1. At the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.
2. Press the  key to address the **Shelf** number. Then press the  key or the  keys to scroll to the number of the desired shelf.
3. Press the  key. The **Slot** field is highlighted.
4. Press the  key or the  key to scroll to the number of the desired slot.
5. Press the  key. The information for the module of interest is now displayed on the ICIM screen.
6. When you have reached the desired module's location, press the  key.
7. Press the  key or the  key to scroll through the monitored parameters until you find the parameter of interest.
8. Check the status of the desired parameter or select other parameters to monitor. When finished, press the  key to return to the **MAIN** menu.

## STATUS Menus

Press the  key to select the **STATUS** menu. Typical **STATUS** menus are shown below.

| STATUS                        | STATUS                        | STATUS                        | STATUS                        |
|-------------------------------|-------------------------------|-------------------------------|-------------------------------|
| Shelf 0<br>Slot 10            | Shelf 0<br>Slot 10            | Shelf 0<br>Slot 10            | Shelf 0<br>Slot 10            |
| 1310nm<br>Reverse<br>Transmit | 1310nm<br>Reverse<br>Transmit | 1310nm<br>Reverse<br>Transmit | 1310nm<br>Reverse<br>Transmit |
| OutPwr<br>8.2 dBm             | InRF<br>-11.5 dB              | TecCur<br>-225 mA             | Enable<br>On                  |
| LasBias<br>123 mA             | ModTemp<br>54.3 degC          | LasTemp<br>25.5 degC          | CwMode<br>Off                 |
| ▲ ▼                           | ▲ ▼                           | ▲ ▼                           | ▲ ▼                           |

## Monitoring Operating Status Using the ICIM, Continued

---

| STATUS                        | STATUS                         |
|-------------------------------|--------------------------------|
| Shelf 0                       | Shelf 0                        |
| Slot 10                       | Slot 10                        |
| 1310nm<br>Reverse<br>Transmit | 1310nm<br>cReverse<br>Transmit |
| LoRFInh<br>OFF                | RFDrive<br>0.0 dB              |
| Master<br>Master<br>▲ ▼       |                                |


















# Configuring the 1310 nm Reverse Transmitter Using the ICIM

---

## Configuring Parameters

Using the ICIM, you can configure the parameters listed above. To configure the parameters, follow these steps.

1. From the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.
2. Press the  key to address the **Shelf** number. Then press the  key or the  key to scroll to the number of the desired shelf.
3. When the desired shelf number is displayed, press the  key. The **Slot** field is highlighted.
4. Press the  key or the  keys to scroll to the number of the desired slot.
5. When the desired slot number is displayed, press the  key. The initial information for the module of interest is now displayed on the ICIM screen.
6. To configure the module, press the  key.
7. Press the  key or the  key to scroll through the configurable controls until you find the parameter of interest.
8. Press the  key to select the highlighted control.
9. Press the  key or the  key to activate or change the value of the selected control.
10. Press the  key to save the changes and return to the MAIN menu.

## Configuring the 1310 nm Reverse Transmitter Using the ICIM, Continued

---




### Configurable Parameters

Configurable parameters for this module include the following.

| Parameter | Function  | Values                             | Default |
|-----------|---|------------------------------------|---------|
| Enable    | Enables or disables transmitter operation, i.e., turns the laser on or off.   | ON or OFF                          | ON      |
| CwMode    | Automatically adjusts the displayed RF input level by subtracting 3 dB when CW mode is on. The RF high alarm is also disabled when CW mode is on.   | ON or OFF                          | OFF     |
| LoRFInh   | Enables or disables the "RF input low" alarm.   | ON or OFF                          | ON      |
| Master    | Configures the module as master or slave. If set to Master, the transmitter is controlled <i>only</i> by the Enable control above. If set to Slave, the transmitter is controlled by a combination of Enable and the external input CNT_IN_1. | Master or Slave                    | Master  |
| RFDrive   | Sets the relative RF drive level into the transmitter.  | -1.5 dB to +1.5 dB in 0.5 dB steps | 0.0 dB  |

# Configuring the 1310 nm Reverse Transmitter Using the ICIM, Continued

## CONFIG Menus

When the **CONFIG** menu is selected, the **Shelf** number field is highlighted. The shelf and slot number fields may only be incremented with the  key or the  key. The  key highlights the **Slot** number field. Once you exit the slot field, the up/down arrows will scroll through the parameters that are specific to this module. Sample Prisma II 1310 nm Reverse Transmitter **CONFIG** menus are shown below.

|  |  |  |  |
|--|--|--|--|
| <pre> CONFIG ----- Shelf  0 Slot   10 -----  1310nm Reverse Transmit ----- Enable CwMode LoRFInh Master RFDrive                     </pre> | <pre> CONFIG ----- Shelf  0 Slot   10 -----  1310nm Reverse Transmit ----- Enable ON                     </pre>        | <pre> CONFIG ----- Shelf  0 Slot   10 -----  1310nm Reverse Transmit ----- CwMode OFF                     </pre> | <pre> CONFIG ----- Shelf  0 Slot   10 -----  1310nm Reverse Transmit ----- LoRFInh ON                     </pre> |
| <pre> CONFIG ----- Shelf  7 Slot   10 -----  1310nm Reverse Transmit ----- Master Master                     </pre>                        | <pre> CONFIG ----- Shelf  7 Slot   10 -----  1310nm Reverse Transmit ----- RFDrive 0.500 dB                     </pre> |  |  |

# Checking 1310 nm Reverse Transmitter Alarms Using the ICIM

---













## Checking Alarms

If the red ALARM LED on the front panel is blinking, a minor alarm condition is indicated. If the ALARM LED on the front panel is illuminated, a critical alarm condition is indicated.

Alarms fall into one of the following categories.

- Major low
- Minor low
- Minor high
- Major high

To check alarm conditions follow these steps.

1. From the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.
2. Press the  key to address the **Shelf** number. Then press the  key or the  keys to scroll to the number of the desired shelf.
3. Press the  key. The **Slot** field is highlighted.
4. Press the  key or the  key to scroll to the number of the desired slot.
5. Press the  key. The information for the module of interest is now displayed on the ICIM menu.
6. Press the  key. The module alarm conditions are displayed here.
7. Use the  key or the  key to scroll through alarm conditions until the desired alarm is displayed.
8. Monitor the alarm condition(s). Take appropriate action. Verify that all settings and thresholds relating to the alarm indication are set correctly to rule out an unintended alarm.
9. When finished, press the  key. The display returns to the MAIN menu.

## Checking 1310 nm Reverse Transmitter Alarms Using the ICIM, Continued

### Alarm Data Display

The alarm data for this module is shown below.

| Alarm   | Alarm Condition      | Range               | Possible Cause                                 |
|---------|----------------------|---------------------|--|
| InRF    | RF Input level       | -4.5 dB to +3.0 dB  | RF source or cables                            |
| OutPwr  | Optical output power | ±0.5 dBm of nominal | Internal problem                               |
| CwMode  | CW mode              | Fault               | CwMode set to ON                               |
| LasTemp | Laser temperature    | 20°C to 30°C        | Internal problem                               |
| LasBias | Laser bias current   | 50 mA to 100 mA     | Internal problem                               |
| Enable  | Laser off            | Fault               | Check Enable and Master CONFIG settings        |
| PsOK    | Bus voltage status   | Fault               | Module not fully seated.<br>Check power supply |

### 1310 nm Reverse Transmitter ALARM Menus

When a module's **ALARM** menu is selected, press the  key or the  key to scroll through alarms. Some typical **ALARMS** menus are shown below.

|  |  |   |   |
|--|--|---|---|
| <b>ALARMS</b><br>-----<br>Shelf 0<br>Slot 10<br>-----<br>1310nm<br>Reverse<br>Transmit<br>-----<br>InRF<br>MinL<br>▲ ▼ | <b>ALARMS</b><br>-----<br>Shelf 0<br>Slot 10<br>-----<br>1310nm<br>Reverse<br>Transmit<br>-----<br>OutPwr<br>MinH<br>▲ ▼ | <b>ALARMS</b><br>-----<br>Shelf 0<br>Slot 10<br>-----<br>1310nm<br>Reverse<br>Transmit<br>-----<br>CwMode<br>Fault<br>▲ ▼ | <b>ALARMS</b><br>-----<br>Shelf 0<br>Slot 10<br>-----<br>1310nm<br>Reverse<br>Transmit<br>-----<br>LasTemp<br>MajH<br>▲ ▼ |
|--|--|---|---|

# Checking 1310 nm Reverse Transmitter Alarms Using the ICIM, Continued

---

| ALARMS   | ALARMS   | ALARMS   |
|----------|----------|----------|
| Shelf 0  | Shelf 0  | Shelf 0  |
| Slot 10  | Slot 10  | Slot 10  |
| -----    | -----    | -----    |
| 1310nm   | 1310nm   | 1310nm   |
| Reverse  | Reverse  | Reverse  |
| Transmit | Transmit | Transmit |
| -----    | -----    | -----    |
| LasBias  | Enable   | PsOk     |
| MinH     | Fault    | Fault    |
| ▲ ▼      | ▲ ▼      |          |

# Checking 1310 nm Reverse Transmitter Alarms Using the ICIM, Continued

## Setting User Alarm Thresholds

User alarms have adjustable thresholds. To change a user alarm threshold from the factory default, follow the steps below.

1. At the **MODULE** menu, press the **STAT** key. The **STATUS** menu is displayed on the ICIM.
2. Press the **SEL** key. The alarm thresholds previously set are displayed. If the label **n/a** is displayed, you cannot configure that alarm threshold. Press the **▼** key to highlight the next parameter's alarm threshold.
3. When the threshold that you wish to set is highlighted, press the **ENTER** key.
4. Press the **+** key or the **☐** key to adjust the alarm threshold.
5. Press the **ENTER** key to save the changes. **Data Saved** is displayed.
6. When finished, press the **MAIN** key to return to the **MAIN** menu.

## 1310 nm Reverse Transmitter Alarm Threshold Menus









Some typical alarm threshold menus are shown below.

| STATUS                        | STATUS                        |
|-------------------------------|-------------------------------|
| Shelf 0                       | Shelf 0                       |
| Slot 10                       | Slot 10                       |
| -----                         |                               |
| 1310nm<br>Reverse<br>Transmit | 1310nm<br>Reverse<br>Transmit |
| -----                         |                               |
| InRF                          | OutPwr                        |
| MajH3.000                     | MajH5.250                     |
| MinH1.500                     | MinH4.750                     |
| MinL-4.500                    | MinL3.750                     |
| MajL-1000                     | MajL3.250                     |



# Checking Manufacturing Data Using the ICIM

## Checking Manufacturing Data

The Manufacturing Data information listed above may be displayed on the ICIM menu. To access the module's Manufacturing Data, follow these steps.

1. From the MAIN menu, press the  key to highlight the **Shelf** and **Slot** fields.
2. Press the  key to address the **Shelf** number. Then press the  key or the  keys to scroll to the number of the desired shelf.
3. Press the  key. The **Slot** field is highlighted.
4. Press the  key or the  key to scroll to the number of the desired slot.
5. Press the  key. The **MODULE menu for this module is selected, as shown on the left below. Press the  key to enter the start of the manufacturing data screens, as shown on the right below.**

| MODULE    | MFG. DATA |
|-----------|-----------|
| -----     | -----     |
| Shelf 0   | Shelf 0   |
| Slot 10   | Slot 10   |
| -----     | -----     |
| 1310nm    | 1310nm    |
| Reverse   | Reverse   |
| Transmit  | Transmit  |
| -----     | -----     |
| Alarms    | Module    |
|           | Type      |
| -----     |           |
| Mfg. Data | 1001      |
|           |           |
| ▲ ▼       | ▲ ▼       |

6. The  or  keys allow you to scroll through the manufacturing data.





## Checking Manufacturing Data Using the ICIM, Continued

### Manufacturing Data Display

The table below describes the manufacturing data available for this module.

| Manufacturing Data        | Typical Values  |
|---------------------------|---|
| Module                    | 1310 nm Reverse Transmit                                      |
| Module Type               | 1005  |
| Serial #                  | !ABCDEFG  |
| Date Code                 | J01   |
| Sw Ver (Software Version) | CCB607  |
| Scrp Ver (Script Version) | 24  |
| In Service Hours          | 100   |
| Spec data                 | Special data  |
| Restore Factory Defaults  | Restores the module's factory default configuration settings. |

### MFG. DATA Menus

When the **MFG. DATA** menu is selected, the  key or the  key allows you to scroll through the manufacturing parameters specific to this module. Sample **MFG. DATA** menus are shown below.

|   |   |   |   |
|---|---|---|---|
| <b>MFG. DATA</b><br>-----<br>Shelf 0<br>Slot 10<br>-----<br>1310nm<br>Reverse<br>Transmit<br>-----<br>Module<br>Type<br>1005<br>▲ ▼ | <b>MFG. DATA</b><br>-----<br>Shelf 0<br>Slot 10<br>-----<br>1310nm<br>Reverse<br>Transmit<br>-----<br>Serial #<br>AAYCUA<br>Date Code<br>J01<br>▲ ▼ | <b>MFG. DATA</b><br>-----<br>Shelf 0<br>Slot 10<br>-----<br>1310nm<br>Reverse<br>Transmit<br>-----<br>SW Rev<br>CCB607<br>Script Ver<br>24<br>▲ ▼ | <b>MFG. DATA</b><br>-----<br>Shelf 0<br>Slot 10<br>-----<br>1310nm<br>Reverse<br>Transmit<br>-----<br>In Service<br>Hours<br>100<br>▲ ▼ |
|---|---|---|---|

# Checking Manufacturing Data Using the ICIM, Continued

---

```
MFG . DATA
-----
Shelf   0
Slot   10
-----
  1310nm
Reverse
Transmit
-----
Spec Data

▲ ▼
```

```
MFG . DATA
-----
Shelf   0
Slot   10
-----
  1310nm
Reverse
Transmit
-----
Restore
Factory
Defaults
```

# Using the ICIM to Save the Configuration

---

## Saving the Current Configuration

To save the current module configuration, follow these steps after every change.

1. After you have changed a parameter or entered data, press the **ENTER** key to save the changes and return to the MAIN menu.
2. If you do not save your changes for two minutes, or if you press the **SHIFT** **CAN** keys at the same time, changes are aborted and the display returns to the MAIN menu.

## Configuration Complete

Once you have configured the module using the ICIM to your system's specifications, and no alarms are indicated, no further action is necessary. The module operates without further input. Alarms, changes in operating parameters, electrical power fluctuations, or changes in system design may be cause for additional action.

# Chapter 4

## Operation Using LCI

### Overview

---

#### Introduction

The installation steps and procedures in this chapter apply if you are using the Local Craft Interface (LCI) to operate the Prisma II 1310 nm Reverse Transmitter.

#### Scope of this Chapter

Included in this chapter are LCI installation instructions and detailed descriptions of how to use LCI to view and modify information for the transmitter.

#### In This Chapter

This chapter contains the following topics.

| <b>Topic</b>                                   | <b>See Page</b> |
|--|-----------------|
| LCI Introduction                               | 4-3             |
| System Requirements                            | 4-4             |
| Installing LCI                                 | 4-5             |
| Connecting Your Laptop Computer to the Chassis | 4-9             |
| Starting LCI                                   | 4-10            |
| LCI Module Tree Overview                       | 4-11            |
| Accessing the Module Details Window            | 4-13            |

## Overview, Continued

---

| Topic  | See Page |
|--|----------|
| Checking the Operating Status                      | 4-20     |
| Configuring the 1310 nm Reverse Transmitter        | 4-22     |
| Checking 1310 nm Reverse Transmitter Alarms        | 4-25     |
| Modifying 1310 nm Reverse Transmitter Alarm Limits | 4-27     |
| Checking Manufacturing Data                        | 4-29     |



**WARNING:**

**Avoid damage to your eyes! Do not look into any optical connector while the system is active. Even if the unit is off, there may still be hazardous optical levels present.**

# LCI Introduction

---

## LCI Function

LCI is software that functions as a user interface for the Prisma II platform. LCI is installed on a laptop computer, which is then connected to a Prisma II Chassis. Using LCI, you can configure and monitor the modules in the chassis the computer is connected to.

**Important!** Do not operate any Prisma II Chassis without a Fan Tray installed. If a Fan Tray is not installed in the Prisma II Chassis, the LCI will not communicate with the power supplies in that chassis.

# System Requirements

---

## Introduction

You will need the following computer software and hardware to run LCI.

## Laptop Computer Requirements

- Pentium II® 300 MHz processor or equivalent
- 128 MB RAM
- 10 MB available hard drive space
- 1.44 MB floppy drive
- CD-ROM Drive
- Windows® 95 or later operating system software

## Connecting the PC to the Prisma II Chassis

The required cable is a standard “off the shelf” DB9 Female to DB9 Male serial extension cable. The connectors are a serial 9-pin D-shell (EIA 574/232).

The Cisco part number for a six-foot DB9 Female to DB9 Male extension cable is 180143.

# Installing LCI

---

## Introduction

This section describes how to install your LCI software.


## Installing the LCI Software

To install LCI, follow these steps.

1. Close all programs that are running on your computer.
2. Insert the LCI CD-ROM into your CD-ROM drive.

**Result:** The LCI Installation program starts automatically.

3. Click **Next**.




**Result:** The License Agreement screen displays.



## Installing LCI, Continued


---

4. Click **Yes** to accept the license agreement.



**Result:** The License Agreement Confirmation dialog box displays.

5. Click **Yes**.




**Result:** The Destination Folder screen displays.


## Installing LCI, Continued

---

6. Do you want to install LCI in the specified folder?
  - If **yes**, click **Next** to begin the installation, and go to step 10.
  - If **no**, click **Browse**, and go to step 7.



7. To specify where you want LCI to be installed, type the path in the **Path** box, or select it in the **Directories** box.




8. Click **OK**.  
**Result:** The Destination Folder screen displays.
9. Click **Next** to begin the installation.  
**Result:** The last installation wizard screen displays after the installation is complete.

## Installing LCI, Continued

---


10. Click **Finish**.

**Note:** You have the option to select the **Do not display LCI for Prisma II information** check box. This bypasses the registration card that you can fill out to receive product updates.



**Result:** LCI is installed, and the Registration Information file displays.

11. Follow the instructions in the file.



# Connecting Your Laptop Computer to the Chassis

---

## Introduction


Before you start LCI, you must first connect your laptop computer to the chassis that contains the module(s) you want to check.

**Important:** LCI communicates only with those modules located in the chassis your computer is attached to. To check other modules, you must connect your computer to the chassis they're located in.

## Connecting to the Chassis

To connect your laptop to the chassis, follow these steps.

1. Plug one end of a nine-pin serial extension cable into your computer.
2. Plug the other end of the cable into the LCI port. This port is labeled "Local Craft Interface".



# Starting LCI

---

## Introduction

When LCI is started, it polls the module(s) located in the chassis your computer is attached to. For each module it finds, LCI does the following:

- Represents the module in the module tree of the main LCI window
- Makes the polling information available so you can check and configure various parameters

**Important:** Your computer must be connected to the chassis before you start LCI. For instructions, refer to **Connecting Your Laptop Computer to the Chassis** earlier in this chapter.


## Starting LCI

To start the software, double-click the LCI icon on your Windows desktop.



### Results:

- LCI polls the modules in the chassis
- The main LCI window displays




# LCI Module Tree Overview

---

## Introduction

The main window of LCI contains a tree that represents your system in a hierarchical manner.



## Module Tree

In the graphic above, the module tree represents a laptop connected to a chassis that contains ten modules. The three tree levels are described in the following table.

| Module Tree Level | Description   |
|-------------------|---|
| Local (System 0)  | Laptop computer being used  |
| Chass00 (Chassis) | Chassis the computer is connected to  |
| Sxx (Module name) | Module(s) located within the chassis. Each module is of the format <i>chassis slot location (module name)</i> .<br><br><b>Example:</b> In the graphic above, <b>S08 (Transmitter)</b> represents a Prisma II 1310 nm Reverse Transmitter that's located in slot eight of the chassis. |

## LCI Module Tree Overview, Continued

---

### Module Information

Information about a module (its parameters, alarms and statuses) is located in the Module Details window. Within the module tree, you can access this window using one of the following four methods:

- Double-click the chassis and select the module in the graphic that displays
- Right-click the chassis and select **Open** from the menu that displays
- Double-click the module
- Right-click the module and select **Details** from the menu that displays

**Note:** Although you can use the method that's most convenient for you, the procedures throughout this chapter are described using the right-click module technique.

For more information about each of these methods, refer to the next section, **Accessing the Module Details Window**.

# Accessing the Module Details Window

## Introduction

Information about a module (its parameters, alarms and statuses) is located in the Module Details window. The graphic below shows the Module Details window for a Prisma II 1310 nm Reverse Transmitter.

The screenshot displays the 'Chas00.S07 p2131xr Transmitter Details' window for a 1310nm Reverse Transmitter. It is divided into several sections: Parameters, Alarms, Controls, Status, and Properties.

| Present Value | Present Status | Nominal Value | Minor Alarm Low Limit | Minor Alarm High Limit | Major Alarm Low Limit | Major Alarm High Limit | Unit  |
|---------------|----------------|---------------|-----------------------|------------------------|-----------------------|------------------------|-------|
| 24.9          | Normal         | 25.0          | -5                    | 5                      | -15                   | 15                     | deg-C |
| 0.6           | Normal         | 35.0          | 10                    | 10                     | 20                    | 20                     | mA    |
| 0.4           | Normal         | 0.0           | -4.9                  | 1.9                    | -1000.9               | 3.7                    | dBm   |
| 6.2           | Normal         | 6.0           | -50.0                 | 1.3                    | -25.0                 | 1.9                    | dBm   |

**Alarms**  
Summary Status: Normal  
Communication Status: Normal  
Power Supply Status: Normal  
Laser Temperature Status: Normal  
Laser Bias Status: Normal  
RF Input Status: Normal  
Output Power Status: Normal

**Controls**  
RF Drive Setting: -1.0 dB  
Enable Laser: OFF  
CW Mode Control: OFF  
Low RF Alarm Inhibit: OFF  
Master: OFF

**Status**  
Module Temperature: 22.7 deg-C  
TEC Current: 0.8 mA

**Properties**  
Name: S07  
Alarm Promotion: Yes  
Graphic: Graphic  
Service Name: Service Name  
Symbol: Symbol  
M&C Scan: On Scan  
Maintenance Mode: Normal  
Poll Counter: 425  
Port: COM1  
Address: 7  
Description: 1310nm Reverse Transmitter  
Software Revision: 6.06  
Script Version: 24  
Serial Number: Serial Number  
Time Of Service: 649 Hrs  
Module Type: 1005

Within LCI's module tree, you can access this window using one of the following four methods:

- Double-click the chassis and select the module in the graphic that displays
- Right-click the chassis and select **Open** from the menu that displays
- Double-click the module
- Right-click the module and select **Details** from the menu that displays

**Note:** Although you can use the method that's most convenient for you, the procedures throughout this chapter are described using the right-click module technique.

For more information about the module tree, refer to **LCI Module Tree Overview** earlier in this chapter.




## Accessing the Module Details Window, Continued

---


### Double-Click the Chassis

To access the Module Details window, follow these steps.

1. Double-click the chassis.



**Result:** A graphic representation of the chassis displays.



## Accessing the Module Details Window, Continued

- Double-click the module whose information you want to view and/or configure.

**Result:** The Module Details window displays.

The screenshot shows a window titled "Chas00.S07 p213tx Transmitter Details" for a "1310nm Reverse Transmitter". The window is divided into several sections:

| Parameters           |                |               |                       |                        |                       |                        |       |
|----------------------|----------------|---------------|-----------------------|------------------------|-----------------------|------------------------|-------|
| Present Value        | Present Status | Nominal Value | Minor Alarm Low Limit | Minor Alarm High Limit | Major Alarm Low Limit | Major Alarm High Limit |       |
| Laser Temperature    | 24.9           | Normal        | 25.0                  | 5                      | 5                     | 15                     | deg-C |
| Laser Bias Current   | 0.5            | Normal        | 35.0                  | 1.0                    | 1.0                   | 20                     | mA    |
| RF Input Power       | 0.4            | Normal        | 0.0                   | 4.9                    | 1.9                   | 1000.9                 | dBm   |
| Optical Output Power | 6.2            | Normal        | 6.0                   | 50.0                   | 1.3                   | 25.0                   | dBm   |

**Alarms**

- Summary Status: Normal
- Communication Status: Normal
- Power Supply Status: Normal
- Laser Temperature Status: Normal
- Laser Bias Status: Normal
- RF Input Status: Normal
- Output Power Status: Normal

**Controls**

- RF Drive Setting: -1.0 dB
- Enable Laser: Off
- CW Mode Control: Off
- Low RF Alarm Inhibit: Off
- Master: Off

**Properties**

- Name: S07
- Alarm Promotion: Yes
- Graphic: Yes
- Service Name: Symbol
- M&C Scan: On-Scan
- Maintenance Mode: Normal
- Poll Counter: 425
- Port: COM1
- Address: 7
- Description: 1310nm Reverse Transmitter
- Software Revision: 6.36
- Serial Number: 24
- Time Of Service: 649 Hrs
- Module Type: 1005

**Status**

- Module Temperature: 22.7 deg-C
- TEC Current: 0.8 mA

- Proceed with viewing and/or configuring information.


## Accessing the Module Details Window, Continued

---


### Right-Click the Chassis

To access the Module Details window, perform these steps.

1. Right-click the chassis, and click **Open**.



**Result:** A graphic representation of the chassis displays.



## Accessing the Module Details Window, Continued

- Double-click the module whose information you want to view and/or configure.

**Result:** The Module Details window displays.

The screenshot shows a window titled "Chas00.S07 p213tx Transmitter Details" for a "1310nm Reverse Transmitter". The window is divided into several sections:

| Parameters           |                |               |                       |                        |                       |                        |       |
|----------------------|----------------|---------------|-----------------------|------------------------|-----------------------|------------------------|-------|
| Present Value        | Present Status | Nominal Value | Minor Alarm Low Limit | Minor Alarm High Limit | Major Alarm Low Limit | Major Alarm High Limit |       |
| Laser Temperature    | 24.9           | Normal        | 25.0                  | 5                      | 5                     | 15                     | deg-C |
| Laser Bias Current   | 0.5            | Normal        | 35.0                  | 1.0                    | 1.0                   | 25                     | mA    |
| RF Input Power       | 0.4            | Normal        | 0.0                   | 4.9                    | 1.9                   | 1000.9                 | dBm   |
| Optical Output Power | 6.2            | Normal        | 6.0                   | 50.0                   | 1.3                   | 25.0                   | dBm   |

**Alarms**

- Summary Status: Normal
- Communication Status: Normal
- Power Supply Status: Normal
- Laser Temperature Status: Normal
- Laser Bias Status: Normal
- RF Input Status: Normal
- Output Power Status: Normal

**Status**

- Module Temperature: 22.7 deg-C
- TEC Current: 0.8 mA

**Controls**

- RF Drive Setting: -1.0 dB
- Enable Laser: Off
- CW Mode Control: Off
- Low RF Alarm Inhibit: Off
- Master: Off

**Properties**

- Name: S07
- Alarm Promotion: Yes
- Graphic: Yes
- Service Name: Symbol
- M&C Scan: On-Scan
- Maintenance Mode: Normal
- Poll Counter: 425
- Port: COM1
- Address: 7
- Description: 1310nm Reverse Transmitter
- Software Revision: 6.36
- Serial Number: 24
- Time Of Service: 649 Hrs
- Module Type: 1005


- Proceed with viewing and/or configuring information.

# Accessing the Module Details Window, Continued


## Double-Click the Module

To access the Module Details window, perform these steps.

1. Double-click the module.



**Result:** The Module Details window displays.




2. Proceed with viewing and/or configuring information.

# Accessing the Module Details Window, Continued


## Right-Click the Module

To access the Module Details window, perform these steps.

1. Right-click the module, and click **Details**.



**Result:** The Module Details window displays.



2. Proceed with viewing and/or configuring information.

# Checking the Operating Status

---

## Introduction

Using LCI, you can check the status of all operating parameters of the Prisma II 1310 nm Reverse Transmitter.

## Monitored Parameters

The table below describes the monitored parameters for the Prisma II 1310 nm Reverse Transmitter.


| <b>Displayed Parameter</b> | <b>Units</b> | <b>Function</b>                               |
|----------------------------|--------------|---|
| Optical Output Power       | dBm          | Displays optical output power.                |
| Laser Bias Current         | mA           | Displays laser bias current.                  |
| RF Input Power             | dB           | Displays RF input level.                      |
| Module Temperature         | °C           | Displays module temperature.                  |
| TEC Current                | mA           | Displays laser thermoelectric cooler current. |
| Laser Temperature          | °C           | Displays laser temperature.                   |
| RF Drive Setting           | N/A          | RF drive level                                |
| Enable Laser               | N/A          | Laser on/off                                  |
| Cw Mode Control            | N/A          | Continuous wave mode operation                |
| Low RF Alarm Inhibit       | N/A          | Low RF alarm enabled/disabled                 |
| Master                     | N/A          | Master or Slave operation                     |

# Checking the Operating Status, Continued


## Checking the Operating Status

To monitor the Prisma II 1310 nm Reverse Transmitter operating parameters, follow these steps.

1. In the module tree, right-click the Prisma II 1310 nm Reverse Transmitter, and click **Details**.



**Result:** The Module Details window displays. The monitored parameters are displayed under **Parameters** and **Status**.



2. Proceed with checking the operating parameters.



# Configuring the 1310 nm Reverse Transmitter

---

## Introduction

Using LCI, you can configure the parameters listed below.

## Configurable Parameters

Configurable parameters for the Prisma II 1310 nm Reverse Transmitter are listed below.


| Parameter            | Function  | Values                                     | Default |
|----------------------|---|--|---------|
| RF Drive Setting     | Sets the relative RF drive level into the transmitter.  | -1.5 dB to +1.5 dB in 0.5 dB steps         | 0.0 dB  |
| Enable Laser         | Enables or disables transmitter operation, i.e. turns the laser on or off   | On = Enabled<br>Off = Disabled             | Enabled |
| CwMode Control       | Automatically adjusts the displayed RF input level by subtracting 3 dB when CW mode is on. The RF high alarm is also disabled when CW mode is on.   | On<br>Off                                  | Off     |
| Low RF Alarm Inhibit | Enables or disables the "RF input low" alarm.   | On = Alarm enabled<br>Off = Alarm disabled | Enabled |
| Master               | Configures the module as master or slave. If set to Master, the transmitter is controlled <i>only</i> by the Enable control above. If set to Slave, the transmitter is controlled by a combination of Enable and the external input CNT_IN_1. | On = Master<br>Off = Slave                 | Master  |

# Configuring the 1310 nm Reverse Transmitter, Continued


## Configuring Parameters

To configure the parameters, follow these steps.

1. In the module tree, right-click the Prisma II 1310 nm Reverse Transmitter, and click **Details**.



**Result:** The Module Details window displays.




## Configuring the 1310 nm Reverse Transmitter, Continued

---

2. Under **Controls**, double-click the parameter you want to configure.

**Result:** The Change Value dialog box displays. The graphic below shows the dialog box for the Enable Laser parameter.



3. Depending on the parameter you chose, select or type a new value.
4. Click **Execute**.

**Result:** The new value displays next to the parameter.

# Checking 1310 nm Reverse Transmitter Alarms

---

## Introduction

Using LCI, you can check the alarm status of various parameters. Alarms that you can check are listed below.

| <b>Alarm</b>         | <b>Alarm Condition</b> | <b>Range</b>        | <b>Possible Cause</b>                           |
|----------------------|------------------------|---------------------|---|
| Laser Temperature    | Laser Temperature      | 20 to 30 °C         | Internal problem                                |
| Laser Bias Current   | Laser Bias             | 50 to 100 mA        | Internal problem                                |
| RF Input Power       | RF Input level         | -4.5 to +3.0 dB     | RF source or cables.                            |
| Optical Output Power | Optical Output Power   | ±0.5 dBm of nominal | Internal problem                                |
| Power Supply Status  | Power Supply Status    | Normal or Alarm     | Module not fully seated.<br>Check power supply. |

Alarms limits fall into one of the following categories.


- Major low
- Minor low
- Minor high
- Major high

# Checking 1310 nm Reverse Transmitter Alarms, Continued

## Checking Alarms

To check a parameter's alarm status, perform these steps.

1. Right-click the Prisma II 1310 nm Reverse Transmitter, and click **Details**.



**Result:** The Module Details window displays. The alarms are shown under **Parameters and Alarms**.

The screenshot shows the 'Chas00.S07 p213txr Transmitter Details' window. The title bar reads 'Chas00.S07 p213txr Transmitter Details' and '1310nm Reverse Transmitter'. The main content is divided into several sections: 'Parameters', 'Alarms', 'Controls', 'Properties', and 'Status'.

| Parameters           |                | Minor Alarm   | Minor Alarm | Major Alarm | Major Alarm |            |       |     |
|----------------------|----------------|---------------|-------------|-------------|-------------|------------|-------|-----|
| Present Value        | Present Status | Nominal Value | Low Limit   | High Limit  | Low Limit   | High Limit |       |     |
| Laser Temperature    | 22.9           | Normal        | 25.0        | 5           | -15         | 15         | deg-C |     |
| Laser Bias Current   | 0.5            | Normal        | 35.0        | -10         | 10          | 30         | mA    |     |
| RF Input Power       | 0.4            | Normal        | 0.0         | 4.9         | 1.9         | 1000.9     | dBm   |     |
| Optical Output Power | 6.2            | Normal        | 6.0         | 50.0        | 1.3         | 25.0       | 1.9   | dBm |

**Alarms**

|                          |        |
|--------------------------|--------|
| Summary Status           | Normal |
| Communication Status     | Normal |
| Power Supply Status      | Normal |
| Laser Temperature Status | Normal |
| Laser Bias Status        | Normal |
| RF Input Status          | Normal |
| Output Power Status      | Normal |

**Controls**

|                      |      |    |
|----------------------|------|----|
| RF Drive Setting     | -1.0 | dB |
| Enable Laser         | Off  |    |
| CW Mode Control      | Off  |    |
| Low RF Alarm Inhibit | Off  |    |
| Master               | Off  |    |

**Properties**

|                   |                            |
|-------------------|----------------------------|
| Name              | S07                        |
| Alarm Promotion   | Yes                        |
| Graphic           | Graphic                    |
| Service Name      | Symbol                     |
| M&C Scan          | On-Scan                    |
| Maintenance Mode  | Normal                     |
| Poll Counter      | 625                        |
| Port              | COM1                       |
| Address           | 7                          |
| Description       | 1310nm Reverse Transmitter |
| Software Revision | 0.36                       |
| Script Version    | 24                         |
| Serial Number     |                            |
| Time Of Service   | 649 Hrs                    |
| Module Type       | 1005                       |

**Status**

|                    |      |       |
|--------------------|------|-------|
| Module Temperature | 22.7 | deg-C |
| TEC Current        | 0.8  | mA    |

2. If any of the parameters are in alarm, take the corrective action you deem necessary.

# Modifying 1310 nm Reverse Transmitter Alarm Limits

## Introduction


Using LCI, you can modify alarm limits for several parameters. Parameters whose alarm limits you can change are listed below.

| Alarm                | Alarm Condition      | Range               | Possible Cause       |
|----------------------|----------------------|---------------------|----------------------|
| RF Input Power       | RF Input level       | -4.5 to +3.0 dB     | RF source or cables. |
| Optical Output Power | Optical Output Power | ±0.5 dBm of nominal | Internal problem     |

## Modifying Alarm Limits

To modify a parameter's alarm limit, follow these steps.

1. In the module tree, right-click the Prisma II 1310 nm Reverse Transmitter, and click **Details**.



**Result:** The Module Details window displays. The alarm limits are shown under **Parameters**.

The screenshot shows the '1310nm Reverse Transmitter Details' window. The 'Parameters' section contains the following table:

| Present Value | Present Status | Nominal Value | Minor Alarm |            | Major Alarm |            | Unit  |
|---------------|----------------|---------------|-------------|------------|-------------|------------|-------|
|               |                |               | Low Limit   | High Limit | Low Limit   | High Limit |       |
| 24.9          | Normal         | 25.0          | 5           | 5          | 15          | 15         | deg-C |
| 0.5           | Normal         | 25.0          | 10          | 10         | 25          | 25         | mA    |
| 0.4           | Normal         | 0.0           | -4.5        | 3.9        | -1000.3     | 3.7        | dBm   |
| 6.2           | Normal         | 6.0           | 50.0        | 1.3        | 29.0        | 1.9        | dBm   |


Below the Parameters table, there are sections for 'Alarms', 'Controls', and 'Properties'.

## Modifying 1310 nm Reverse Transmitter Alarm Limits, Continued

---

2. Double-click the limit you want to change.

**Result:** The Change Value dialog box displays. The graphic below shows the dialog box for the major low limit of the RF Input Power parameter.



3. In the **Command to** box, type the value to use for the limit.
4. Click **Execute**.

**Result:** The new value displays in the alarm limit column.

# Checking Manufacturing Data

---

## Introduction

Using LCI, you can check the manufacturing data of the 1310 nm Reverse Transmitter.

## Manufacturing Data

The table below describes the manufacturing data available for this module.

| <b>Manufacturing Data</b> | <b>Typical Values</b>      |
|---------------------------|----------------------------|
| Description               | 1310nm Reverse Transmitter |
| Serial number             | !ABCDEFG                   |
| Software Revision         | 6.06                       |
| Script Version            | 24                         |
| Time of Service           | 1                          |
| Module Type               | 1005                       |




# Checking Manufacturing Data, Continued


## Checking Manufacturing Data

To access the module's manufacturing data, perform these steps.

1. In the module tree, right-click the Prisma II 1310 nm Reverse Transmitter, and click **Details**.



**Result:** The Module Details window displays. The manufacturing data is displayed under **Properties**.



2. Proceed with viewing the manufacturing data.

# Chapter 5

## Maintenance and Troubleshooting

### Overview

---

#### Introduction

This chapter describes the maintenance guidelines and troubleshooting procedures for the Prisma II Reverse Transmitter.

#### Qualified Personnel

Only appropriately qualified and trained personnel should attempt to maintain or troubleshoot these products.



**WARNING:**

**Allow only qualified personnel to install, operate, maintain, and service these products. Otherwise, personal injury or equipment damage may occur.**

#### In This Chapter

This chapter contains the following topics.

| Topic                               | See Page |
|-------------------------------------|----------|
| Prisma Module Maintenance           | 5-2      |
| General Troubleshooting Information | 5-3      |
| Troubleshooting Alarm Conditions    | 5-4      |

# Prisma Module Maintenance

---

## Maintaining the Prisma Module

To ensure optimal performance, the following maintenance is recommended.

| Frequency   | Maintenance Required   |
|-------------|--|
| Weekly      | <ul style="list-style-type: none"><li>• Check all parameters and test points</li><li>• Record data</li><li>• Make adjustments as needed</li></ul>  |
| Quarterly   | <ul style="list-style-type: none"><li>• Make sure all cables are mated properly</li><li>• Inspect cables for stress and chafing</li><li>• Make sure all retaining screws are tight</li></ul> |
| When needed | Carefully clean the module with a soft cloth that is dampened with mild detergent  |

## Maintenance Record

It may be helpful to establish a maintenance record or log for this module. You may want to record laser power level, laser temperature readings, laser bias current, or power supply voltages.

Large variations in any of the parameters above should be investigated prior to failure.

# General Troubleshooting Information

---

## Introduction

This troubleshooting information describes the most common alarms and gives typical symptoms, causes, and items to check before consulting Cisco Services.

## Equipment Needed

You may need the following equipment to troubleshoot these modules.

- Digital voltmeter
- Fiber connector cleaning materials

## Additional Assistance

If you need additional assistance contact Cisco Services.

## Troubleshooting



### **WARNING:**

**Avoid electric shock and damage to this product! Do not open the enclosure of this product. There are no user-serviceable parts inside. Refer servicing to qualified service personnel.**

Refer to the following section, **Troubleshooting Alarm Conditions**, to identify and correct Laser Module faults.

# Troubleshooting Alarm Conditions

---

## Reverse Transmitter Alarm Conditions

If the red ALARM indicator is illuminated or is blinking, refer to the chart below to determine the cause of the alarm. If you are unable to determine the cause of the alarm, telephone Cisco Services for help.

| Alarm   | Alarm Condition      | Range               | Possible Cause                                 |
|---------|----------------------|---------------------|--|
| InRF    | RF Input level       | -4.5 dB to +3.0 dB  | RF source or cables                            |
| OutPwr  | Optical output power | ±0.5 dBm of nominal | Internal problem                               |
| CwMode  | CW mode              | Fault               | CwMode set to ON                               |
| LasTemp | Laser temperature    | 20°C to 30°C        | Internal problem                               |
| LasBias | Laser bias           | 50 mA to 100 mA     | Internal problem                               |
| Enable  | Enabled              | Fault               | Check Enable and Master CONFIG settings        |
| PsOK    | Bus voltage status   | Fault               | Module not fully seated.<br>Check power supply |

# Chapter 6

## Customer Information

### Overview

---

#### If You Have Questions

If you have technical questions, call Cisco Services for assistance. Follow the menu options to speak with a service engineer.

Access your company's extranet site to view or order additional technical publications. For accessing instructions, contact the representative who handles your account. Check your extranet site often as the information is updated frequently.

# Glossary

---

| <b>Term, Acronym, Abbreviation</b> | <b>Meaning</b>  |
|------------------------------------|---|
| <b>A</b>                           | Ampere (amp) is the unit of measure for electrical current.   |
| <b>AC</b>                          | Alternating current   |
| <b>Addressable</b>                 | The ability to control an individual unit in a system of many similar units.  |
| <b>AFC</b>                         | Automatic Frequency Control   |
| <b>AGC</b>                         | Automatic Gain Control  |
| <b>AM</b>                          | Amplitude Modulation  |
| <b>Amplifier Cascade</b>           | Two or more amplifiers in a series, the output of one feeding the input of another.   |
| <b>ATC</b>                         | Automotive fuse   |
| <b>Attenuation</b>                 | A decrease in signal magnitude occurring in transmission from one point to another or in passing through a loss medium.                       |
| <b>Attenuator</b>                  | A device designed to reduce signal strength by an amount specified in dB.   |
| <b>ATX</b>                         | Addressable transmitter   |
| <b>AUX</b>                         | Auxiliary   |
| <b>Baseband</b>                    | The total signal before it is modified for transmission or otherwise manipulated.   |
| <b>Baud (Bd)</b>                   | A measure of signaling rate based on the number of signaling events per unit of time  |
| <b>bdr™</b>                        | Baseband digital reverse  |
| <b>Beamwidth</b>                   | The included angle between two rays (usually the half-power points) on the radiation pattern, which includes the maximum lobe, of an antenna. |
| <b>BER</b>                         | Bit error rate  |

## Glossary, Continued

---

|                          |  |
|--------------------------|--|
| <b>BERT</b>              | Bit error rate test  |
| <b>BIG</b>               | Broadband Integrated Gateway   |
| <b>BIOS</b>              | Basic Input/Output System  |
| <b>BIST</b>              | Built-in self-test   |
| <b>Bit</b>               | Short for Binary Digit. Can be either a "one" or a "zero."   |
| <b>Blanking level</b>    | The amplitude of the front and back porches of the composite video signal.   |
| <b>BNC</b>               | A coaxial connector that uses a bayonet type attachment to secure the cable. It is also known as Baby N connector.   |
| <b>BPF</b>               | Bandpass filter  |
| <b>bps</b>               | Bits per second - The total number of bits sent in a second of time.   |
| <b>BPSK</b>              | Binary Phase Shift Keying  |
| <b>BW</b>                | Bandwidth  |
| <b>Byte</b>              | A group of bits treated as a unit  |
| <b>CF</b>                | Continuous feed  |
| <b>Circuit switching</b> | The type of signal switching traditionally used by telephone companies to create a physical connection between a caller and a called party.                                  |
| <b>CIRD</b>              | Commercial Integrated Receiver Decoder   |
| <b>CIM</b>               | Communications Interface Module  |
| <b>CISC</b>              | Complex Instruction Set Computer. A computer that uses many different types of instructions to conduct its operations, i.e., IBM PCs, Apple Macintosh's, IBM 370 mainframes. |
| <b>CIU</b>               | Customer Interface Unit  |
| <b>C/N or CNR</b>        | Carrier-to-noise ratio   |



## Glossary, Continued

---

|                          |  |
|--------------------------|--|
| <b>Compression</b>       | The non-linear change of gain at one level of a signal with respect to the change of gain at another level for the same signal. Also, the elimination of redundant information from an audio, data, or video signal to reduce transmission requirements. |
| <b>CSO</b>               | Composite Second Order   |
| <b>CTB</b>               | Composite Triple Beat  |
| <b>C/T</b>               | Carrier-to-noise temperature ratio   |
| <b>CW</b>                | Continuous Wave  |
| <b>dB</b>                | Decibel  |
| <b>dBc</b>               | Decibels relative to a reference carrier   |
| <b>DBDS</b>              | Digital Broadband Delivery System  |
| <b>dBm</b>               | Decibels relative to 1 milliwatt   |
| <b>dB<sub>i</sub></b>    | Decibels of gain relative to an isotropic radiator   |
| <b>dBuV</b>              | Decibels relative to 1 microvolt   |
| <b>dBW</b>               | Decibels relative to 1 watt  |
| <b>dBmV</b>              | Decibels relative to 1 millivolt   |
| <b>DC</b>                | Direct current   |
| <b>DC</b>                | Directional coupler  |
| <b>DES</b>               | Data Encryption Standard   |
| <b>Deviation</b>         | The peak difference between the instantaneous frequency of the modulated wave and the carrier frequency, in an FM system.  |
| <b>DFB</b>               | Distributed feed back laser  |
| <b>Differential gain</b> | The difference in amplification of a signal (superimposed on a carrier) between two different levels of carrier.   |
| <b>Diplex filter</b>     | A filter which divides the frequency spectrum into a high frequency segment and a low frequency segment so that two different signals can be sent down the same transmission path.   |

## Glossary, Continued

---

|                            |  |
|----------------------------|--|
| <b>Distribution System</b> | Part of a cable system consisting of trunk and feeder cables used to carry signals from headend to subscriber terminals. |
| <b>Downconverter</b>       | A device that converts an input signal to a lower frequency output signal.   |
| <b>Down link</b>           | A transmission path carrying information from a satellite or spacecraft to earth.  |
| <b>DP</b>                  | Data processing  |
| <b>DPU</b>                 | Digital processing unit  |
| <b>DSP</b>                 | Digital signal processor   |
| <b>DSR</b>                 | Digital Storage and Retrieval System   |
| <b>D to U</b>              | Desired to undesired signal ratio  |
| <b>DTMF</b>                | Dual Tone Multiple Frequency   |
| <b>Duplexer</b>            | A device which permits the connection of both a receiver and a transmitter to a common antenna.                          |
| <b>DVM</b>                 | Digital voltmeter  |
| <b>DWDM</b>                | Dense Wave Division Multiplexing   |
| <b>ECM</b>                 | Entitlement Control Message  |
| <b>EDFA</b>                | Erbium Doped Fiber Amplifier   |
| <b>EEPROM</b>              | Electrically Erasable Programmable Read-Only Memory  |
| <b>EIA</b>                 | Electronics Industry Association   |
| <b>EMI</b>                 | Electromagnetic interference   |
| <b>Emission designer</b>   | An FCC or CCIR code that defines the format of radiation from a transmitter.   |
| <b>EPROM</b>               | Erasable Programmable Read-Only Memory   |
| <b>EQ</b>                  | Equalizer  |
| <b>Equalization</b>        | The process of compensating for an undesired result. For example, equalizing tilt in a distribution system.              |
| <b>ERP</b>                 | Effective radiated power   |

## Glossary, Continued

---

|                             |   |
|-----------------------------|---|
| <b>FAOC</b>                 | Frequency agile output converters   |
| <b>FET</b>                  | Field-effect transistor   |
| <b>FIFO</b>                 | First in, first out   |
| <b>FM</b>                   | Frequency modulation  |
| <b>Forward path</b>         | Signal direction from the headend to the set-top terminal.  |
| <b>FP</b>                   | Fabry-Perot laser   |
| <b>Fiber</b>                | A single strand of glass used as an optical transmission medium; or a bundle of glass strands in a CATV system.   |
| <b>Frequency</b>            | The number of similar shapes in a unit of time. For example, the number of sine waves moving past a fixed point in a second.  |
| <b>Frequency Agile</b>      | The ability to change from one frequency to another without changing components.  |
| <b>Frequency Modulation</b> | A system of modulation where the instantaneous radio frequency of the carrier varies in proportion to the instantaneous amplitude of the modulating signal while the amplitude of the radio frequency carrier is independent of the amplitude of the modulating signal. |
| <b>Frequency Response</b>   | The effect that changing the frequency has on the magnitude of a signal.  |
| <b>Frequency Reuse</b>      | A technique in which independent information is transmitted on orthogonal polarizations to "reuse" a given band of frequencies.   |
| <b>Frequency Stability</b>  | A measure of the departure from nominal frequency value of a signal, with respect to time, temperature, or other influence.   |
| <b>FSM</b>                  | Field strength meter  |
| <b>FSK</b>                  | Frequency-shift keying  |
| <b>ft-lb.</b>               | Foot-pound  |
| <b>FTP</b>                  | File Transfer Protocol  |
| <b>Gain</b>                 | An increase in signal relative to a reference   |
| <b>Gbps</b>                 | Gigabits per second   |

## Glossary, Continued

---

|                  |  |
|------------------|--|
| <b>Headend</b>   | Location and equipment that receives data from a satellite (or other) source and reformats that data for input to a broadband distribution network |
| <b>HEDA</b>      | Headend Driver Amplifier   |
| <b>HGD</b>       | High Gain Dual   |
| <b>Hertz</b>     | A unit of frequency equal to one cycle per second.   |
| <b>Hetrodyne</b> | Changing the frequency of a signal by mixing it with another signal to get the sum and difference of the two.                                      |
| <b>I/O</b>       | Input/output   |
| <b>IC</b>        | Integrated circuit   |
| <b>ICIM</b>      | Intelligent Communications Interface Module  |
| <b>ICP</b>       | Internal Control Program. A series of policies to protect company sensitive and export controlled information.                                     |
| <b>IDR</b>       | Intermediate Data Rate   |
| <b>IEC</b>       | International Electrotechnical Commission  |
| <b>IF</b>        | Intermediate frequency   |
| <b>IFL</b>       | Interfacility link   |
| <b>IP</b>        | Internet protocol  |
| <b>Kbps</b>      | Kilobits per second  |
| <b>in-lb</b>     | Inch-pound   |
| <b>LCD</b>       | Liquid crystal display   |
| <b>LCI</b>       | Local craft interface  |
| <b>LED</b>       | Light-emitting diode   |
| <b>LIFO</b>      | Last-in, first-out   |
| <b>LNA</b>       | Low-noise amplifier  |
| <b>LNB</b>       | Low-noise block converter  |

## Glossary, Continued

---

|   |  |
|---|--|
| <b>LNC</b>                                | Low-noise converter  |
| <b>LOCATE(TM)</b>                         | Systems for monitoring, analyzing, or reporting electric power outages   |
| <b>Mbps</b>                               | Megabits per second  |
| <b>MCU</b>                                | Master Control Unit  |
| <b>Multipath (multipath transmission)</b> | The phenomenon which results from a signal traveling from point to point by more than one path so that several copies of the signal arrive at the destination at different times or at different angles. |
| <b>mux</b>                                | multiplexed  |
| <b>Nanosecond</b>                         | 1 thousandth of a microsecond  |
| <b>Nm</b>                                 | Newton meter   |
| <b>NIU</b>                                | Network Interface Unit   |
| <b>Node</b>                               | A branching or exchange point  |
| <b>OEM</b>                                | Original equipment manufacturer  |
| <b>OOB</b>                                | Out of band  |
| <b>OIM</b>                                | Optical interface module   |
| <b>PCB</b>                                | Printed circuit board  |
| <b>PCM</b>                                | Pulse code modulation  |
| <b>PDI</b>                                | Pressure differential indicator  |
| <b>PDU</b>                                | Power distribution unit  |
| <b>PLL</b>                                | Phase Lock Loop. An electronic servo system controlling an oscillator to maintain a constant phase angle relative to a reference signal.   |
| <b>PROM</b>                               | Programmable Read Only Memory  |
| <b>PWB</b>                                | Printed wiring board   |
| <b>QAM</b>                                | Quadrature Amplitude Modulation  |
| <b>QPR</b>                                | Quadrature Partial Response  |

## Glossary, Continued

---

|                     |   |
|---------------------|---|
| <b>QPSK</b>         | Quadrature Phase-Shift Keying   |
| <b>RC</b>           | Reverse conditioner   |
| <b>Reverse path</b> | Signal flow direction toward the headend.   |
| <b>RF</b>           | Radio frequency   |
| <b>RF Bypass</b>    | A bypass feature that allows subscribers to view a clear analog channel while recording a digital or analog channel on a VCR.                               |
| <b>RFI</b>          | Radio frequency interference  |
| <b>RMA</b>          | Return material authorization   |
| <b>RMS</b>          | Root Mean Square  |
| <b>Router</b>       | A data communications device which examines a packet and routes the packet to an output port appropriate to the packet destination                          |
| <b>RS</b>           | Remote Sensing  |
| <b>RX</b>           | Receive or receiver   |
| <b>SA</b>           | Spectrum analyzer   |
| <b>SAM</b>          | Signal analysis meter   |
| <b>SAT</b>          | Site acceptance test  |
| <b>S-band</b>       | The group of frequencies between 2 and 4 GHz.   |
| <b>SET</b>          | Secure electronic transaction   |
| <b>Scattering</b>   | Random directional change of a wave or part of a wave caused by an irregular reflecting surface or by passing through an inhomogeneous transmission medium. |
| <b>SLM</b>          | Signal level meter  |
| <b>SM</b>           | Status monitor  |
| <b>SMC</b>          | Status monitoring and control   |
| <b>SMIU</b>         | Status Monitor Interface Unit   |
| <b>SMU</b>          | Server Management Unit  |
| <b>S/N or SNR</b>   | Signal-to-noise ratio   |

## Glossary, Continued

---

|                                 |   |
|---------------------------------|---|
| <b>SNMP</b>                     | Simple Network Management Protocol  |
| <b>SP</b>                       | Splitter. It is a device which divides power from an input to deliver multiple outputs or combines multiple inputs into one output. |
| <b>Spread Spectrum</b>          | A modulation technique to spread a narrow band signal over a wide band of frequencies.  |
| <b>Spurious</b>                 | Anything other than the desired result  |
| <b>SSPA</b>                     | Solid-state power amplifier   |
| <b>Sweep generator</b>          | A signal source which can automatically vary its frequency continuously from one frequency to another.                              |
| <b>Synchronous transmission</b> | A method of sending information over a path and separating discrete characters and symbols by a precise separation in time.         |
| <b>TCP/IP</b>                   | Transmission control protocol/internet protocol   |
| <b>TDM</b>                      | Time division multiplexing  |
| <b>TNCS</b>                     | Transmission Network Control System   |
| <b>Torque</b>                   | Force applied to bolt or screw to tighten the device.   |
| <b>TS</b>                       | Transport Stream  |
| <b>TTCN</b>                     | True tilt correction network  |
| <b>Tx</b>                       | Transmit or transmitter   |
| <b>UBT</b>                      | Unbalanced triple   |
| <b>UPS</b>                      | Un-interruptible power supply   |
| <b>Upstream</b>                 | Signal transmission toward the headend  |
| <b>UTP</b>                      | Unshielded twisted pair   |
| <b>uV</b>                       | One millionth of a volt (microvolt)   |
| <b>V</b>                        | Volt  |
| <b>V AC</b>                     | Volts alternating current   |
| <b>VBR</b>                      | Variable bit rate   |

## Glossary, Continued

---

|              |  |
|--------------|--|
| <b>VCA</b>   | Voltage controlled attenuator          |
| <b>V DC</b>  | Volts direct current                   |
| <b>VOD</b>   | Video-on-demand                        |
| <b>VOM</b>   | Volt ohm meter                         |
| <b>W</b>     | Watts                                  |
| <b>WDM</b>   | Wave Division Multiplexing             |
| <b>YEDFA</b> | Ytterbium/Erbium Doped Fiber Amplifier |





Cisco Systems, Inc.  
5030 Sugarloaf Parkway, Box 465447  
Lawrenceville, GA 30042

678 277-1120  
800 722-2009  
[www.cisco.com](http://www.cisco.com)

This document includes various trademarks of Cisco Systems, Inc. Please see the Notices section of this document for a list of the Cisco Systems, Inc. trademarks used in this document.

Product and service availability are subject to change without notice.

© 2001, 2008, 2013 Cisco and/or its affiliates.

All rights reserved.

January 2013 Printed in USA

Part Number 78-715190-01 Rev C