

Release Notes for Cisco NCS 4000 Series, Cisco IOS XR Release 6.5.28

First Published: 2019-10-09

Release Notes for Cisco NCS 4000 Series, Cisco IOS XR Release 6.5.28



Note Come to the Content Hub at content.cisco.com, where, using the Faceted Search feature, you can accurately zoom in on the content you want; create customized PDF books on the fly for ready reference; and can do so much more...

So, what are you waiting for? Click content.cisco.com now!

And, if you are already experiencing the Content Hub, we'd like to hear from you!

Click the **Feedback** icon on the page and let your thoughts flow!

The release notes contain information about the new features introduced in the Cisco NCS 4000 Series. For detailed information regarding features, capabilities, hardware, and software introduced with this release, see the guides listed in the *Additional References* section.

Revision History

Date	Notes
October 2019	This is the first release of this publication.

Software and Hardware Requirements

Before you begin to install the software, you must check whether your system meets the minimum software and hardware requirements.

- Hardware— Intel Core i5, i7, or faster processor. A minimum of 4 GB RAM, 100 GB hard disk with 250 MB of available hard drive space.
- One of these operating System:
 - Windows 7, Windows Server 2008, or later.
 - Apple Mac OS X
 - UNIX workstation with Solaris Version 9 or 10 on an UltraSPARC-III or faster processor, with a minimum of 1 GB RAM and a minimum of 250 MB of available hard drive space.

- Ubuntu 12.10
- Java Runtime Environment—Java Runtime Environment Version 1.8.
- Browser:
 - Internet Explorer
 - Mozilla
 - Safari
 - Google Chrome

New Features for Release 6.5.28



Note Before you dive into this release's features, we invite you to content.cisco.com to experience the features of the [Cisco Content Hub](#). Here, you can, among other things:

- Create customized books to house information that's relevant only to you.
- Collaborate on notes and share articles by experts.
- Benefit from context-based recommendations.
- Use faceted search to close in on relevant content.

And, if you are already experiencing the Content Hub, we'd like to hear from you!

Click the **Feedback** icon on the page and let your thoughts flow!

This section highlights new NCS 4000 features for Release 6.5.28:

Software

The following software features have been introduced in Release 6.5.28:

Laser Squelching

Squelching supports the laser shutdown of the client signal when there is a failure in the OTN network. When the network is down, squelching saves power. The Squelched alarm is raised on the client controller when the laser is squelched. Squelching is supported on the NCS4K-24LR-O-S, NCS4K-2H10T-OP-KS, and NCS4K-4H-OPW-QC2 cards.

Idle Frames

Idle frames are used to prevent unnecessary switching at the client end. When there is a fault in the client signal, valid idles frames are sent in the downstream direction on the ten GigE, forty GigE, or hundred GigE client interface instead of raising an AIS or LF. This prevents unnecessary switching at the client end. Idle frames are supported on the ethernet mapper ODUs of the NCS4K-4H-OPW-QC2 card.

Port Optimization

The number of QSFP+ pluggables used on the client and network side of the NCS4K-4H-OPW-QC2 card can be optimised.

For more information on the above software features, see the *Configuration Guide for Cisco NCS 4000 Series*.

Hardware

The following hardware has been introduced in Release 6.5.28:

QSFP to SFP+ Adapter

QSFP to SFP+ adapter (PID: CVR-QSFP-SFP10G) is a pluggable adapter module that allows a SFP+ optical module to be plugged in to QSFP+ ports (ports 0 to 9) of the NCS4K-4H-OPW-QC2 line card. The QSFP to SFP+ adapter provides 10G support on the NCS4K-4H-OPW-QC2 line card.

For details regarding the adapter, see the Installing Route Processor Cards, Fabric Cards, and Line Cards chapter of the *Hardware Installation Guide for Cisco NCS 4000 Series*.

Support for ACBEL Power Module

The NCS 4000 chassis supports the ACBEL power module. When a Delta power module is replaced with an ACBEL power module, and if the software version is an older one, then, there are a few limitations with respect to the behavior of the ACBEL power modules.

For details of the limitations, see the Removing and Replacement chapter of the *Hardware Installation Guide for Cisco NCS 4000 Series*.

External Caveats

External Bugs in Release 6.5.28

The following list contains known issues for Release 6.5.28:

Caveat ID Number	Description
CSCvq41605	Card Improper Removal alarms are cleared with shelf-mgr (RM-ACT) restart
CSCvq42506	Circuit edit fails, when circuit creation is stuck
CSCvq85826	Once ECU SSD is re-inserted, raise an alarm to indicate that node reload is required for recovery
CSCvq90909	After multiple rp reload on iteration 17 we see the smaug fpd not ready
CSCvr30965	FIA process forced reload, on peer interface shut
CSCvr38119	Fia crash observed after Rack reload
CSCvr39903	0/RP1 disk provisioning is in progress
CSCvr49053	6528-11I: Got crash "otn_framer_digi400g" after otn_framer_digi400g process restart

Supported FPD Versions

The following table lists the FPD versions supported in Release 6.5.28

FPD	FPD Description	Req. Reload	S/W Version	Min. Req. S/W Version
NCS4009-FC-S	CCC-FPGA	No	1.05	1.05
	CCC-Power-On	No	1.03	1.03
	PLX-8608	Yes	0.03	0.03
NCS4009-FC2-S	CCC-FPGA	No	2.05	2.05
	CCC-Power-On	No	1.03	1.03
	PLX-8714	Yes	0.04	0.04
NCS4009-FC2-SP	CCC-FPGA	No	1.11	1.11
	CCC-Power-On	No	1.03	1.03
	PLX-8608	Yes	0.03	0.03
NCS4009-FC2F-S	CCC-FPGA	No	2.05	2.05
	CCC-Power-On	No	1.03	1.03
	PLX-8714	Yes	0.04	0.04
NCS4016-FC-M	CCC-FPGA	No	4.40	4.40
	CCC-Power-On	No	1.14	1.14
	PLX-8649	Yes	0.08	0.08
NCS4016-FC-S	CCC-FPGA	No	5.07	5.07
	CCC-Power-On	No	1.01	1.01
	PLX-8649	Yes	0.08	0.08
NCS4016-FC-S	CCC-FPGA	Yes	0.05	0.01
	CCC-Power-On	Yes	1.12	1.08
	PLX-8649	Yes	0.08	0.08
NCS4016-FC2-M	CCC-FPGA	No	1.35	1.35
	CCC-Power-On	No	1.03	1.03
	PLX-8649	Yes	1.00	1.00
NCS4K-2OT-O-S	CCC-FPGA	No	4.39	4.39
	CCC-Power-On	No	1.21	1.21
	Ethernet - Switch	Yes	1.38	1.38
	PLX-8618	Yes	0.11	0.11

NCS4K-24LR-O-S	CCC-FPGA	No	4.39	4.39
	CCC-Power-On	No	1.21	1.21
	Ethernet - Switch	Yes	1.38	1.38
	PLX-8618	Yes	0.11	0.11
NCS4K-2H-O-K	CCC-FPGA	No	3.38	3.38
	CCC-Power-On	No	1.19	1.19
	Ethernet - Switch	Yes	1.41	1.41
	PLX-8618	Yes	0.10	0.10
NCS4K-2H-W	CCC-FPGA	No	4.34	4.34
	CCC-Power-On	No	1.20	1.20
	Ethernet - Switch	Yes	1.35	1.35
	PLX-8608	Yes	0.10	0.10
NCS4K-2H10T-OP-KS	CCC-FPGA	No	1.50	1.50
	CCC-Power-On	No	1.14	1.14
	Ethernet - Switch	Yes	1.02	1.02
	PLX-8649	Yes	0.11	0.11
NCS4K-4H-OP-K	CCC-FPGA	Yes	2.02	2.02
	CCC-Power-On	Yes	1.09	1.09
	Ethernet - Switch	Yes	1.01	1.01
	PLX-8649	Yes	0.01	0.01
NCS4K-4H-OPW-QC2	CCC-FPGA	No	0.29	0.29
	CCC-Power-On	No	1.12	1.12
	Ethernet-Switch	Yes	1.51	1.51
	PLX-8750	Yes	0.10	0.10

NCS4K-AC-PSU	AB-PriMCU	No	1.31	1.31
	AB-Sec54vMCU	No	1.49	1.49
	AB-Sec5vMCU	No	1.43	1.43
	DT-PriMCU	No	3.00	3.00
	DT-PriMCU	No	1.06	1.06
	DT-PriMCU	No	2.01	2.01
	DT-Sec54vMCU	No	4.00	4.00
	DT-Sec54vMCU	No	2.03	2.03
	DT-Sec54vMCU	No	3.02	3.02
	DT-Sec5vMCU	No	3.01	3.01
	DT-Sec5vMCU	No	1.09	1.09
	DT-Sec5vMCU	No	2.02	2.02
	NCS4K-CRAFT	Craft-NCS4009	No	1.04
Craft-NCS4016		No	1.04	1.04
NCS4K-DC-PSU-V1	AB-PriMCU	No	4.01	4.01
	AB-Sec54vMCU	No	4.02	4.02
	AB-Sec5vMCU	No	4.03	4.03
	DT-Pri2MCU	No	3.02	3.02
	DT-PriMCU	No	3.02	3.02
	DT-Sec54v2MCU	No	3.01	3
	DT-Sec54v2MCU	No	3.01	3
	DT-Sec54vMCU	No	3.08	3.08
NCS4K-ECU	ECU-FPGA	No	3.01	3.01
NCS4K-ECU2	ECU-FPGA	No	4.08	4.08
NCS4K-FTA	Fantray-FPGA	No	3.01	3.01

NCS4K-RP	BACKUP-BIOS	Yes	14.04	1.00
	Backup-CCC-PwrOn	Yes	1.22	1.00
	Backup-Ethswitch	Yes	1.36	1.00
	Backup-Timing	Yes	3.95	3.00
	BP-FPGA	No	3.21	3.21
	CCC-Bootloader	Yes	4.29	4.08
	CCC-FPGA	Yes	4.29	4.29
	CCC-Power-On	Yes	1.23	1.23
	CPU-Complex-Boot	Yes	2.09	2.04
	CPU-Complex-FPGA	Yes	2.09	2.09
	Ethernet - Switch	Yes	1.36	1.36
	PLX-8649	Yes	0.08	0.08
	PLX-8696	Yes	0.05	0.05
	Primary-BIOS	Yes	14.04	14.04
	Timing FPGA	Yes	3.95	3.95
NCS4KF-CRAFT	Craft-NCS4K-FCC	No	1.07	1.07
NCS4KF-FC2-C	Back-CRE-FPGA-MB	Yes	1.05	1.05
	CCC-FPGA	Yes	1.26	1.26
	CCC-Power-On	Yes	1.05	1.05
	CRE-FPGA-MB	Yes	1.05	1.05
	PLX-8713	Yes	0.06	0.06
NCS4KF-FTA	Backup-Fantray	No	2.03	2.03
	Fantray-FPGA	No	2.04	2.04

NCS4KF-RPMC	Backup-BIOS	Yes	14.09	14.00
	Backup-CCC-PwrOn	No	2.01	1.38
	Backup-EthSwitch	Yes	1.33	1.33
	CCC-Bootloader	Yes	3.07	2.01
	CCC-FPGA	Yes	3.07	3.07
	CCC-Power-On	No	2.01	2.01
	CPU-Complex-BOOT	Yes	4.09	4.04
	CPU-Complex-FPGA	Yes	4.09	4.09
	Ethernet-Switch	Yes	1.33	1.33
	PLX-8625	Yes	0.05	0.05
	Primary-BIOS	Yes	14.09	14.09
	SMART-iSATA	No	7.05	7.05
	SMART-SATA	No	7.05	7.05
NCS4KF-RPMC (SW)	CCC-FPGA	Yes	2.06	2.06
	CCC-Power-On	No	2.01	2.01
	PLX-8614	Yes	0.06	0.06
P-S-FANTRAY	Fantray-FPGA	No	2.04	2.04

Supported Craft Firmware Version

The following table lists the Craft firmware versions supported in Release 6.5.28

Craft	Firmware Version
NCS4K-CRAFT	2.9.46
NCS4KF-CRAFT	2.9.46

Cisco Bug Search Tool

Use the Bug Search Tool (BST) to view the list of outstanding and resolved bugs in a release.

BST, the online successor to Bug Toolkit, is designed to improve the effectiveness in network risk management and device troubleshooting. The tool allows partners and customers to search for software bugs based on product, release, and keyword, and aggregates key data such as bug details, product, and version. The tool has provision to filter bugs based on credentials to provide external and internal bug views for the search input.

Search Bugs in BST

Procedure

-
- Step 1** Go to <https://tools.cisco.com/bugsearch/>. You will be prompted to log into Cisco.com. After successful login, the Bug Toolkit page open.
- Step 2** Enter the bug ID in the Search For: field. To search for release bugs, enter the following parameters in the page:
- Search For — Enter NCS4k in the text box.
 - Releases — Enter the release number.
 - Show Bugs — Select Affecting or Fixed in these Releases
- Step 3** Press Enter.
- By default, the search results include bugs with all severity levels and statuses, and bugs that were modified during the life cycle of the bug. After you perform a search, you can filter your search results to meet your search requirements.
 - An initial set of 25 search results is shown in the bottom pane. Drag the scroll bar to display the next set of 25 results. Pagination of search results is not supported.
-

Additional References

Related Documentation

Use the release notes with the following publications:

Document Title	Description
<i>Hardware Installation Guide for Cisco NCS 4000 Series</i>	Provides installation information about the Cisco NCS 4009 and Cisco NCS 4016 chassis.
<i>Cisco Network Convergence System 4000 Series Unpacking, Moving, and Securing Guide</i>	Provides instructions for unpacking the Cisco NCS 4009 and Cisco NCS 4016 chassis, moving the chassis to its permanent location, and mounting the chassis in a rack.
<i>Regulatory Compliance and Safety Information for the Cisco NCS 4000 Series</i>	Provides the international agency compliance, safety, and statutory information that apply to Cisco NCS 4009 and Cisco NCS 4016 chassis.
<i>Configuration Guide for Cisco NCS 4000 Series</i>	Provides background and reference material, procedures to configure and maintain the Cisco NCS 4009 and Cisco NCS 4016 chassis.

Document Title	Description
<i>Command Reference for Cisco NCS 4000 Series</i>	Provides the various commands available to configure and maintain the Cisco NCS 4009 and Cisco NCS 4016 chassis.
<i>System Setup and Software Installation Guide for Cisco NCS 4000 Series</i>	Provides instructions to set up the system and perform software installation.
<i>Alarms Troubleshooting Guide for Cisco NCS 4000 Series</i>	Provides a description, severity, and troubleshooting procedure for each commonly encountered NCS 4000 alarm and condition.
<i>Cisco IOS XR System Error Message Reference Guide</i>	Provides a list of the Cisco IOS XR system error messages for all Cisco IOS XR platforms
<i>Quality of Service Configuration Guide for Cisco NCS 4000 Series</i>	Provides features available to configure and maintain Quality of Service (QoS) for the Cisco NCS 4000 Series Routers.
<i>Quality of Service Command Reference for Cisco NCS 4000 Series</i>	Provides various commands available to configure and maintain Quality of Service (QoS) for the Cisco NCS 4000 Series Routers.
<i>Migration of Single Chassis to Multi Chassis for Cisco NCS 4000 Series</i>	Provides configuration procedures for the supported multi chassis configurations.

Technical Assistance

Link	Description
http://www.cisco.com/cisco/web/support/index.html	<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.</p>