



# Working with Cisco Spaces: Environmental Analytics App


---

- [Viewing Sensor Performance Data, on page 1](#)
- [Configuring Environmental Analytics Parameters, on page 2](#)
- [Supported Telemetry Types, on page 3](#)
- [View Air Quality Parameters, on page 5](#)
- [View Ambient Noise Parameters, on page 8](#)
- [View Humidity Parameters, on page 9](#)
- [View Temperature Parameters, on page 11](#)
- [Viewing Sensor Data in Floor View, on page 12](#)
- [Compare Floors, on page 17](#)

## Viewing Sensor Performance Data

The **Overview** window displays the performance data of the active sensors available in the floors of the building. The data is displayed for the selected floor for the selected month. Use this data for your analysis.

---

**Step 1** In Cisco Spaces, click the **Menu** icon () and choose **Home > ACT Apps > Environmental Analytics** app tile. Optionally, from the **Dashboard** drop-down list (left navigation pane of the Cisco Spaces **Home** window), select **Environmental Analytics**.

The **Environmental Analytics** window is displayed.

**Step 2** In the left navigation pane, click **Overview**.


The **Overview** window displays the sensor performance data of the active sensors available in the selected root location or the floor for the month.

**Step 3** View the sensor data organized as per the following sections:

- **Air Quality:** Displays the sensor performance data for TVOC, IAQ and PM2.5.
- **Ambient Noise:** Displays the sensor performance data for ambient noise levels.
- **Humidity:** Displays the sensor performance data for humidity levels.


- **Temperature:** Displays the sensor performance data for temperature levels.

- Step 4** (Optional) To view the sensor data for a different floor or month:
- From the **Location** drop-down list, select the root location or floor.
  - From the **Month** drop-down list, select another month.

- Step 5** Click the  icon to open the corresponding parameter configuration window to perform the required updates.

## Configuring Environmental Analytics Parameters

Use the **Settings** tab in the Environmental Analytics app to configure the parameters. Configure these parameters to view the sensor data in the other tabs.

- Step 1** In Cisco Spaces, click the **Menu** icon () and choose **Home > ACT Apps > Environmental Analytics** app tile. Optionally, from the **Dashboard** drop-down list (left navigation pane of the Cisco Spaces **Home** window), select **Environmental Analytics**.

The **Environmental Analytics** window is displayed.

- Step 2** In the left navigation pane, click **Settings**.

The **Environmental Analytics Settings** window is displayed with the telemetry metrics of all sensor devices.

**Figure 1: Settings**

Metric Name	Webex Sensor	AP Sensor	BLE Sensor	Wired Sensor	Wireless Sensor	Meraki Things Sensor
CO2	-	-	-	Active	-	-
IAQ	Active	-	-	-	-	-
TVOC	-	-	-	Active	-	-
PM2.5	-	-	-	-	-	-
Ambient Noise	Active	-	-	-	-	-
Humidity	Active	-	-	Active	-	-
Temperature	Active	-	-	Active	-	-

TVOC  
TVOC's telemetry data will be shown based on the unit selected here

Temperature  
Temperature's telemetry data will be shown based on the unit selected here

**Step 3** In the **Device Type** section, view the following metrics:

- CO<sub>2</sub>
- IAQ
- TVOC
- PM2.5
- Ambient Noise
- Humidity
- Temperature

**Step 4** For each metric, view the following sensor details:

- Webex Sensor
- AP Sensor
- BLE Sensor
- Wired Sensor
- Wireless Sensor
- Meraki Things Sensor

**Note** To view the supported telemetry types, see [Supported Telemetry Types, on page 3](#).

**Step 5** Click **Edit** against the corresponding metric name.

**Step 6** Check or uncheck the check box for the required sensor and click **Save**.

Click **Cancel** to discard the changes, if required.

**Step 7** Click **µg/m<sup>3</sup>** or **PPB** to set the unit for TVOC telemetry data.

The selected unit is highlighted in a blue background.

**Step 8** Click **Celsius** or **Fahrenheit** to set the unit for temperature telemetry data.

The selected unit is highlighted in a blue background.

---

## Supported Telemetry Types

The telemetry types supported for each device type are:

Table 1: Sensor and Supported Telemetry Types

Device Type	Supported Telemetry Types
Cisco Webex	<ul style="list-style-type: none"> <li>• Temperature</li> <li>• Ambient Noise</li> <li>• Humidity</li> <li>• IAQ</li> </ul>
Wired	<ul style="list-style-type: none"> <li>• Temperature</li> <li>• Humidity</li> <li>• CO<sub>2</sub></li> <li>• TVOC</li> </ul>
Access Point	<ul style="list-style-type: none"> <li>• Temperature</li> <li>• Humidity</li> <li>• CO<sub>2</sub></li> <li>• TVOC</li> <li>• IAQ</li> </ul>
Wireless	<ul style="list-style-type: none"> <li>• Temperature</li> <li>• Humidity</li> </ul>
BLE	<ul style="list-style-type: none"> <li>• Temperature</li> <li>• Humidity</li> <li>• CO<sub>2</sub></li> </ul>
Meraki Things	<ul style="list-style-type: none"> <li>• Temperature</li> <li>• Ambient Noise</li> <li>• Humidity</li> <li>• TVOC</li> <li>• IAQ</li> <li>• PM2.5</li> <li>• CO<sub>2</sub></li> </ul>

# View Air Quality Parameters

## Before you begin

Use the **Settings** tab to configure the Air Quality parameters.

**Step 1** In Cisco Spaces, click the **Menu** icon (☰) and choose **Home > ACT Apps > Environmental Analytics** app tile. Optionally, from the **Dashboard** drop-down list (left navigation pane of the Cisco Spaces **Home** window), select **Environmental Analytics**.

The **Environmental Analytics** window is displayed.


**Step 2** In the left navigation pane, click **Air Quality**.

The **Air Quality** window includes the tabs: **IAQ**, **CO2**, **TVOC**, **PM2.5**.

**Step 3** Click the **IAQ** tab.

The floor data with **IAQ** value *Below Moderate* for the selected month is displayed.

**Figure 2: Air Quality Parameters**



a) View the following telemetry details:

- **Floor Name:** Click the floor name to view the details in the **Floor** window. The **Floor Details** window is displayed.
- **Location Path:** Displays the floor location path.

- **# of Workspaces:** Displays the number of workspaces.
- **Max. IAQ:** Displays the maximum IAQ level for the particular floor.
- **Avg. IAQ:** Displays the average IAQ level for the particular floor.
- **Min IAQ:** Displays the minimum IAQ level for the particular floor.
- **Sensor Violation Duration:** Displays the duration of sensor violation.

- b) To view IAQ details of another floor location, from the **Location** drop-down list, select another location.
- c) To view IAQ details of another month, from the **Month** drop-down list, select another month.

#### Step 4

Click the **CO2** tab.

- a) Click **Setup Devices** to configure devices to generate CO2 measurements.
- b) After devices are set, the floor data with CO<sub>2</sub> value as *Below 1000 ppm* is displayed.
- c) View the following telemetry details:

- **Floor Name:** Click the floor name to view the details in the **Floor** window.
- **Location Path:** Displays the floor location path.
- **# of Workspaces:** Displays the number of workspaces.
- **Max. CO2:** Displays the maximum CO<sub>2</sub> level for the particular floor.
- **Avg. CO2:** Displays the average CO<sub>2</sub> level for the particular floor.
- **Min CO2:** Displays the minimum CO<sub>2</sub> level for the particular floor.
- **Sensor Violation Duration:** Displays the duration of sensor violation.

- d) To view CO2 details of another floor location, from the **Location** drop-down list, select another location.
- e) To view CO2 details of another month, from the **Month** drop-down list, select another month.

#### Step 5

Click the **TVOC** tab.

The floor data with **TVOC** value as *Below 3000 µg/m<sup>3</sup>* is displayed.

- a) View the following telemetry details:

- **Floor Name:** Click the floor name to view the details in the **Floor** window.
- **Location Path:** Displays the floor location path.
- **# of Workspaces:** Displays the number of workspaces.
- **Max. TVOC:** Displays the maximum TVOC level for the particular floor.
- **Avg. TVOC:** Displays the average TVOC level for the particular floor.
- **Min TVOC:** Displays the minimum TVOC level for the particular floor.
- **Sensor Violation Duration:** Displays the duration of sensor violation.

- b) To view TVOC details of another floor location, from the **Location** drop-down list, select another location.
- c) To view TVOC details of another month, from the **Month** drop-down list, select another month.

#### Step 6

Click the **PM2.5** tab.

The floor data with PM2.5 value as *Below 35  $\mu\text{g}/\text{m}^3$*  is displayed.

a) View the following telemetry details:

- **Floor Name:** Click the floor name to view the details in the **Floor** window.
- **Location Path:** Displays the floor location path.
- **# of Workspaces:** Displays the number of workspaces.
- **Max. PM2.5:** Displays the maximum PM2.5 level for the particular floor.
- **Avg. PM2.5:** Displays the average PM2.5 level for the particular floor.
- **Min PM2.5:** Displays the minimum PM2.5 level for the particular floor.
- **Sensor Violation Duration:** Displays the duration of sensor violation.

b) To view PM2.5 details of another floor location, from the **Location** drop-down list, select another location.

c) To view PM2.5 details of another month, from the **Month** drop-down list, select another month.

### Step 7


(Optional) Use the following options if required:

- **Search:** Use this field to search for the required floors.
- **Export:** Use this option to export the environmental sensor telemetry details as a comma-separated values file.
- **Show Records:** Use the drop-down to select the number of records to be displayed in the tab. Use the forward and backward arrows to navigate to the other page records.

### Step 8

Click any floor name to view the sensor performance data for the selected floor in detail. For more information, see [Viewing Sensor Data in Floor View](#).


Figure 3: Air Quality Parameters: Floor View



## View Ambient Noise Parameters

### Before you begin

Use the **Settings** tab to configure the Ambient Noise parameters.

**Step 1** In Cisco Spaces, click the **Menu** icon () and choose **Home > ACT Apps > Environmental Analytics** app tile. Optionally, from the **Dashboard** drop-down list (left navigation pane of the Cisco Spaces **Home** window), select **Environmental Analytics**.

The **Environmental Analytics** window is displayed.

**Step 2** In the left navigation pane, click **Ambient Noise**.

The floor data with Ambient Noise value *Below 40 dBa* for the selected month is displayed.

**Step 3** In the window that is displayed, view the following telemetry details:

- **Floor Name:** Click the floor name to view the details in the **Floor** window.
- **Location Path:** Displays the floor location path.
- **# of Workspaces:** Displays the number of workspaces.




- **Max. Ambient Noise:** Displays the maximum Ambient Noise level for the particular floor.
- **Avg. Ambient Noise:** Displays the average Ambient Noise level for the particular floor.
- **Min Ambient Noise:** Displays the minimum Ambient Noise level for the particular floor.
- **Sensor Violation Duration:** Displays the duration of sensor violation.

**Step 4** (Optional) Use the following options if required:

- **Search:** Use this field to search for the required floors.
- **Export:** Use this option to export the environmental sensor telemetry details as a comma-separated values file.
- **Show Records:** Use the drop-down to select the number of records to be displayed in the tab. Use the forward and backward arrows to navigate to the other page records.

**Step 5** If you already clicked a floor name to view other sensor data in floor view, the **Ambient Noise** window is also displayed in **Floor View**. For more information, see [Viewing Sensor Data in Floor View, on page 12](#).

**Figure 4: Ambient Noise: Floor View**



## View Humidity Parameters

### Before you begin

Use the **Settings** tab to configure the Humidity parameters.



- 
- Step 1** In Cisco Spaces, click the **Menu** icon () and choose **Home > ACT Apps > Environmental Analytics** app tile. Optionally, from the **Dashboard** drop-down list (left navigation pane of the Cisco Spaces **Home** window), select **Environmental Analytics**. The **Environmental Analytics** window is displayed.
- Step 2** In the left navigation pane, click **Humidity**. The floor data with Humidity value *Between 30-60%* for the selected month is displayed.
- Step 3** In the window that is displayed, view the following telemetry details:
- **Floor Name:** Click the floor name to view the details in the **Floor** window.
  - **Location Path:** Displays the floor location path.
  - **# of Workspaces:** Displays the number of workspaces.
  - **Max. Humidity:** Displays the maximum Humidity level for the particular floor.
  - **Avg. Humidity:** Displays the average Humidity level for the particular floor.
  - **Min Humidity:** Displays the minimum Humidity level for the particular floor.
  - **Sensor Violation Duration:** Displays the duration of sensor violation.
- Step 4** (Optional) Use the following options if required:
- **Search:** Use this field to search for the required floors.
  - **Export:** Use this option to export the environmental sensor telemetry details as a comma-separated values file.
  - **Show Records:** Use the drop-down to select the number of records to be displayed in the tab. Use the forward and backward arrows to navigate to the other page records.
- Step 5** If you already clicked a floor name to view other sensor data in floor view, the **Humidity** window is also displayed in **Floor View**. For more information, see [Viewing Sensor Data in Floor View](#).

Figure 5: Humidity: Floor View



## View Temperature Parameters

### Before you begin

Use the **Settings** tab to configure the Temperature parameters.

- Step 1** In Cisco Spaces, click the **Menu** icon (☰) and choose **Home > ACT Apps > Environmental Analytics** app tile. Optionally, from the **Dashboard** drop-down list (left navigation pane of the Cisco Spaces **Home** window), select **Environmental Analytics**. The **Environmental Analytics** window is displayed.
- Step 2** In the left navigation pane, click **Temperature**. The floor data with Temperature value *Between 21-25°C* for the selected month is displayed.
- Step 3** In the window that is displayed, view the following telemetry details:
- **Floor Name:** Click the floor name to view the details in the **Floor** window.
  - **Location Path:** Displays the floor location path.
  - **# of Workspaces:** Displays the number of workspaces.


- **Max. Temperature:** Displays the maximum Temperature level for the particular floor.
- **Avg. Temperature:** Displays the average Temperature level for the particular floor.
- **Min Temperature:** Displays the minimum Temperature level for the particular floor.
- **Sensor Violation Duration:** Displays the duration of sensor violation.

**Step 4** (Optional) Use the following options if required:

- **Search:** Use this field to search for the required floors.
- **Export:** Use this option to export the environmental sensor telemetry details as a comma-separated values file.
- **Show Records:** Use the drop-down to select the number of records to be displayed in the tab. Use the forward and backward arrows to navigate to the other page records.


**Step 5** If you already click a floor name to view other sensor data in floor view, the **Temperature** window is also displayed in **Floor View**. For more information, see [Viewing Sensor Data in Floor View](#).

**Figure 6: Temperature: Floor View**



## Viewing Sensor Data in Floor View

You can view the sensor data in floor view for **Air Quality**, **Ambient Noise**, **Humidity**, and **Temperature**.

**Step 1** In Cisco Spaces, click the **Menu** icon () and choose **Home > ACT Apps > Environmental Analytics** app tile. Optionally, from the **Dashboard** drop-down list (left navigation pane of the Cisco Spaces **Home** window), select **Environmental Analytics**.

The **Environmental Analytics** window is displayed.

**Step 2** In the left navigation pane, click any sensor data of your choice.

**Step 3** In the sensor detail window that is displayed, click the floor name.

The **Floor View** window is displayed with the sensor performance data for the selected floor for the current month.


By default, the **All** option is selected and the window displays sensor performance data from all devices. Click **Webex** if you want to view the sensor performance data from Cisco Webex devices.

**Step 4** For the selected sensor data, the following data is displayed in graphical format:

- **Current Month:** Displays the information about sensors that violated the optimal range for a specific time. Click the graph to view the sensor data in detail.
- **Average levels in the floor:** Displays the average levels in the selected floor in graphical format. Click the time range to view additional information. You can again click the graphical format to view the details of the segment.
- **Daily average, min & max levels in floor:** Displays the daily average, minimum and maximum levels in the selected floor in graphical format. Click the time range to view additional information.
- **Cumulative Time in Violation:** Displays the cumulative time in violation in graphical format.
- **By Hour of the Day:** Displays the sensor performance data by an hour of the day.
- **By Day of the Week:** Displays the sensor performance data by day of the week.


For **Air Quality** sensor data, the following window is displayed:

Figure 7: Air Quality Sensor Data




For Ambient Noise sensor data, the following window is displayed:

Figure 8: Ambient Noise Sensor Data




For **Humidity** sensor data, the following window is displayed:

**Figure 9: Humidity Sensor Data**



For **Temperature** sensor data, the following window is displayed:


Figure 10: Temperature Sensor Data



**Step 5** To view the sensor data in Rich Map view, click the **Rich Map** (📍) icon.  
The Floor View is displayed in Rich Maps.



Figure 11: Rich Maps View



- Step 6** (Optional) To download the sensor metric as a CSV file, click **Export as CSV**.
- Step 7** Click **Compare Floors** to open the **Floor Comparison** window to view the floor comparison data. For more information, see [Compare Floors, on page 17](#).
- Step 8** Click the **Close** (✕) icon to close the window.


## Compare Floors

- Step 1** In the Cisco Spaces dashboard, click the **Menu** icon (☰) and choose **Home**.  
Optionally, from the **Dashboard** drop-down list (left navigation pane of the Cisco Spaces **Home** window), select **Environmental Analytics**.  
The **Environmental Analytics** window is displayed.
- Step 2** From the left navigation pane, select any sensor data of your choice.
- Step 3** In the sensor detail window that is displayed, click the floor name.  
The **Floor View** window is displayed with the sensor performance data. The data for the current month is displayed for the selected floor. By default, the **All** option is selected and the window displays sensor performance data from all devices. Click **Webex** if you need to display the sensor performance data from Cisco Webex devices.

**Step 4** In the **Floor View** window, click **Compare Floors**.

The **Floor Comparison** pop-up window is displayed. By default, **All** is selected. Click **Webex** to view sensor data from Cisco Webex devices.

**Figure 12: Floor Comparison**



**Step 5** View the floor comparison data from all the sensors. The floor comparison details such as average sensor trend and sensors in violation for the selected month is displayed.

**Step 6** Hover your cursor over the graph to view additional sensor details.

**Step 7** (Optional) From the **Month** drop-down list, select a different month to view the floor comparison data.